

---

# Instruction Manual

*DP* **harp**

**Model EJA115**  
**Low Flow Transmitter**  
[Style: S2]

IM 1C22K1-01E

---



# CONTENTS

---

|  |            |
|--|------------|
| <b>1. INTRODUCTION</b> .....                                 | <b>1-1</b> |
| WARRANTY .....   | 1-2        |
| <b>2. HANDLING CAUTIONS</b> .....                            | <b>2-1</b> |
| 2.1 Model and Specifications Check .....                     | 2-1        |
| 2.2 Unpacking .....  | 2-1        |
| 2.3 Storage .....  | 2-1        |
| 2.4 Selecting the Installation Location .....                | 2-2        |
| 2.5 Pressure Connection .....                                | 2-2        |
| 2.6 Waterproofing of Cable Conduit Connections .....         | 2-2        |
| 2.7 Restrictions on Use of Radio Transceiver .....           | 2-2        |
| 2.8 Insulation Resistance and Dielectric Strength Test ..... | 2-2        |
| 2.9 Installation of Explosion Protected Type .....           | 2-3        |
| 2.9.1 FM Approval .....                                      | 2-3        |
| 2.9.2 CSA Certification .....                                | 2-5        |
| 2.9.3 SAA Certification .....                                | 2-6        |
| 2.9.4 CENELEC (KEMA)/IEC (KEMA) Certification .....          | 2-7        |
| 2.9.5 JIS Certification .....                                | 2-8        |
| 2.10 EMC Conformity Standards .....                          | 2-9        |
| <b>3. COMPONENT NAMES</b> .....                              | <b>3-1</b> |
| <b>4. INSTALLATION</b> .....                                 | <b>4-1</b> |
| 4.1 Precautions .....  | 4-1        |
| 4.2 Mounting .....   | 4-1        |
| 4.3 Rotating Transmitter Section .....                       | 4-2        |
| <b>5. INSTALLING IMPULSE PIPING</b> .....                    | <b>5-1</b> |
| 5.1 Process Piping Installation Precautions .....            | 5-1        |
| 5.1.1 Connecting Process Piping to the Transmitter .....     | 5-1        |
| 5.1.2 Routing the Process Piping .....                       | 5-1        |
| 5.2 Process Piping Connection Examples .....                 | 5-2        |
| <b>6. WIRING</b> .....                                       | <b>6-1</b> |
| 6.1 Wiring Precautions .....                                 | 6-1        |
| 6.2 Selecting the Wiring Materials .....                     | 6-1        |
| 6.3 Connections of External Wiring to Terminal Box .....     | 6-1        |
| 6.3.1 Power Supply Wiring Connection .....                   | 6-1        |
| 6.3.2 External Indicator Connection .....                    | 6-1        |
| 6.3.3 BRAIN TERMINAL BT200 Connection .....                  | 6-2        |
| 6.3.4 Check Meter Connection .....                           | 6-2        |
| 6.4 Wiring .....   | 6-2        |
| 6.4.1 Loop Configuration .....                               | 6-2        |
| (1) General-use Type and Flameproof Type .....               | 6-2        |
| (2) Intrinsically Safe Type .....                            | 6-2        |
| 6.4.2 Wiring Installation .....                              | 6-3        |
| (1) General-use Type and Intrinsically Safe Type .....       | 6-3        |
| (2) Flameproof Type (JIS) .....                              | 6-3        |

|           |   |            |
|-----------|---|------------|
| 6.5       | Grounding .....   | 6-4        |
| 6.6       | Power Supply Voltage and Load Resistance .....                  | 6-4        |
| <b>7.</b> | <b>OPERATION .....</b>  | <b>7-1</b> |
| 7.1       | Preparation for Starting Operation .....                        | 7-1        |
| 7.2       | Zero Point Adjustment .....                                     | 7-2        |
| 7.3       | Starting Operation .....  | 7-3        |
| 7.4       | Shutting Down Operation .....                                   | 7-3        |
| 7.5       | Transmitter Measurement Range .....                             | 7-3        |
| 7.5.1     | Determining the Differential Pressure Range .....               | 7-3        |
| 7.5.2     | Example of Calculation .....                                    | 7-4        |
| 7.6       | Venting or Draining Transmitter Pressure-detector Section ..... | 7-7        |
| 7.6.1     | Draining Condensate .....                                       | 7-7        |
| 7.6.2     | Venting Gas .....   | 7-7        |
| 7.7       | Setting the Range Using the Range-setting Switch .....          | 7-7        |
| <b>8.</b> | <b>BRAIN TERMINAL BT200 OPERATION .....</b>                     | <b>8-1</b> |
| 8.1       | BT200 Operation Precautions .....                               | 8-1        |
| 8.1.1     | Connecting the BT200 .....                                      | 8-1        |
| 8.1.2     | Conditions of Communication Line .....                          | 8-1        |
| 8.2       | BT200 Operating Procedures .....                                | 8-1        |
| 8.2.1     | Key Layout and Screen Display .....                             | 8-1        |
| 8.2.2     | Operating Key Functions .....                                   | 8-2        |
| (1)       | Alphanumeric Keys and Shift Keys .....                          | 8-2        |
| (2)       | Function Keys .....   | 8-2        |
| 8.2.3     | Calling Up Menu Addresses Using the Operating Keys .....        | 8-3        |
| 8.3       | Setting Parameters Using the BT200 .....                        | 8-4        |
| 8.3.1     | Parameter Summary .....   | 8-4        |
| 8.3.2     | Parameter Usage and Selection .....                             | 8-6        |
| 8.3.3     | Setting Parameters .....  | 8-7        |
| (1)       | Tag No. Setup .....   | 8-7        |
| (2)       | Calibration Range Setup .....                                   | 8-7        |
| (3)       | Damping Time Constant Setup .....                               | 8-8        |
| (4)       | Output Mode and Integral Indicator Display Mode Setup .....     | 8-9        |
| (5)       | Output Signal Low Cut Mode Setup .....                          | 8-9        |
| (6)       | Integral Indicator Scale Setup .....                            | 8-10       |
| (7)       | Unit Setup for Displayed Temperature .....                      | 8-11       |
| (8)       | Unit Setup for Displayed Static Pressure .....                  | 8-12       |
| (9)       | Operation Mode Setup .....                                      | 8-12       |
| (10)      | Output Status Display/Setup when a CPU Failure .....            | 8-12       |
| (11)      | Output Status Setup when a Hardware Error Occurs .....          | 8-12       |
| (12)      | Range Change while Applying Actual Inputs .....                 | 8-13       |
| (13)      | Zero Point Adjustment .....                                     | 8-13       |
| (14)      | Test Output Setup .....   | 8-14       |
| (15)      | User Memo Fields .....  | 8-14       |
| 8.4       | Displaying Data Using the BT200 .....                           | 8-15       |
| 8.4.1     | Displaying Measured Data .....                                  | 8-15       |
| 8.4.2     | Display Transmitter Model and Specifications .....              | 8-15       |
| 8.5       | Self-Diagnostics .....  | 8-15       |
| 8.5.1     | Checking for Problems .....                                     | 8-15       |
| (1)       | Identifying Problems with BT200 .....                           | 8-15       |
| (2)       | Checking with Integral Indicator .....                          | 8-16       |
| 8.5.2     | Errors and Countermeasures .....                                | 8-17       |

|  |                 |
|--|-----------------|
| <b>9. MAINTENANCE .....</b>  | <b>9-1</b>      |
| 9.1 Overview .....   | 9-1             |
| 9.2 Calibration Instruments Selection .....  | 9-1             |
| 9.3 Calibration .....  | 9-1             |
| 9.4 Disassembly and Reassembly .....   | 9-3             |
| 9.4.1 Replacing the Integral Indicator .....   | 9-3             |
| 9.4.2 Replacing the CPU Board Assembly .....   | 9-4             |
| 9.4.3 Replacing the Process Connector Gaskets .....  | 9-4             |
| 9.4.4 Cleaning Manifold Assembly and Replacing Orifice .....                                 | 9-4             |
| 9.4.5 Cleaning and Replacing the Capsule Assembly .....                                      | 9-5             |
| 9.5 Troubleshooting .....  | 9-7             |
| 9.5.1 Basic Troubleshooting .....  | 9-7             |
| 9.5.2 Troubleshooting Flow Charts .....  | 9-7             |
| <b>10. GENERAL SPECIFICATIONS .....</b>  | <b>10-1</b>     |
| 10.1 Standard Specifications .....   | 10-1            |
| 10.2 Model and Suffix Codes .....  | 10-3            |
| 10.3 Optional Specifications .....   | 10-4            |
| 10.4 Dimensions .....  | 10-6            |
| <b>INSTALLATION AND OPERATING PRECAUTIONS FOR<br/>JIS INTRINSICALLY SAFE EQUIPMENT .....</b> | <b>EX-A03E</b>  |
| <b>INSTALLATION AND OPERATING PRECAUTIONS FOR<br/>JIS FLAMEPROOF EQUIPMENT .....</b>         | <b>EX-B03E</b>  |
| <b>Customer Maintenance Parts List</b>   |                 |
| DPharp EJA Series Transmitter Section .....  | CMPL 1C22A1-02E |
| Model EJA115 Low Flow Transmitter .....  | CMPL 1C22K1-01E |
| <b>REVISION RECORD</b>   |                 |



# 1. INTRODUCTION

---

Thank you for purchasing the DPharp electronic pressure transmitter.

The DPharp Pressure Transmitters are precisely calibrated at the factory before shipment. To ensure correct and efficient use of the instrument, please read this manual thoroughly and fully understand how to operate the instrument before operating it.

## ■ Regarding This Manual

- This manual should be passed on to the end user.
- The contents of this manual are subject to change without prior notice.
- All rights reserved. No part of this manual may be reproduced in any form without Yokogawa's written permission.
- Yokogawa makes no warranty of any kind with regard to this manual, including, but not limited to, implied warranty of merchantability and fitness for a particular purpose.
- If any question arises or errors are found, or if any information is missing from this manual, please inform the nearest Yokogawa sales office.
- The specifications covered by this manual are limited to those for the standard type under the specified model number break-down and do not cover custom-made instruments.
- Please note that changes in the specifications, construction, or component parts of the instrument may not immediately be reflected in this manual at the time of change, provided that postponement of revisions will not cause difficulty to the user from a functional or performance standpoint.



## NOTE

For FOUNDATION Fieldbus and HART protocol versions, please refer to IM 1C22T2-01E and IM 1C22T1-01E respectively, in addition to this IM.

---

## ■ Safety Precautions

- For the protection and safety of the operator and the instrument or the system including the instrument, please be sure to follow the instructions on safety described in this manual when handling this instrument. In case the instrument is handled in contradiction to these instructions, Yokogawa does not guarantee safety.
- For the intrinsically safe equipment and explosionproof equipment, in case the instrument is not restored to its original condition after any repair or modification undertaken by the customer, intrinsically safe construction or explosionproof construction is damaged and may cause dangerous condition. Please contact Yokogawa for any repair or modification required to the instrument.
- The following safety symbol marks are used in this Manual:



## WARNING

Indicates a potentially hazardous situation which, if not avoided, *could* result in death or serious injury.

---



## CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against *unsafe practices*.

---



## IMPORTANT

Indicates that operating the hardware or software in this manner may damage it or lead to system failure.

---



## NOTE

Draws attention to information essential for understanding the operation and features.

---

## WARRANTY

- The warranty shall cover the period noted on the quotation presented to the purchaser at the time of purchase. Problems occurred during the warranty period shall basically be repaired free of charge.
- In case of problems, the customer should contact the Yokogawa representative from which the instrument was purchased, or the nearest Yokogawa office.
- If a problem arises with this instrument, please inform us of the nature of the problem and the circumstances under which it developed, including the model specification and serial number. Any diagrams, data and other information you can include in your communication will also be helpful.
- Responsible party for repair cost for the problems shall be determined by Yokogawa based on our investigation.
- The Purchaser shall bear the responsibility for repair costs, even during the warranty period, if the malfunction is due to:
  - Improper and/or inadequate maintenance by the purchaser.
  - Failure or damage due to improper handling, use or storage which is out of design conditions.
  - Use of the product in question in a location not conforming to the standards specified by Yokogawa, or due to improper maintenance of the installation location.
  - Failure or damage due to modification or repair by any party except Yokogawa or an approved representative of Yokogawa.
  - Malfunction or damage from improper relocation of the product in question after delivery.
  - Reason of force majeure such as fires, earthquakes, storms/floods, thunder/lightening, or other natural disasters, or disturbances, riots, warfare, or radioactive contamination.



### WARNING

---

- Instrument installed in the process is under pressure. Never loosen or tighten the process connector bolts as it may cause dangerous spouting of process fluid.
  - During draining condensate or venting gas in transmitter pressure-detector section, take appropriate care to avoid contact with the skin, eyes or body, or inhalation of vapors, if the accumulated process fluid may be toxic or otherwise harmful.  
Since draining condensate or bleeding off gas gives the pressure measurement disturbance, this should not be done when the loop is in operation.
  - Since the accumulated process fluid may be toxic or otherwise harmful, take appropriate care to avoid contact with the body, or inhalation of vapors even after dismantling the instrument from the process line for maintenance.
- 



### CAUTION

---

This instrument is tested and certified as intrinsically safe type or explosionproof type. Please note that the construction of the instrument, installation, external wiring, maintenance or repair is strictly restricted, and non-observance or negligence of this restriction would result in dangerous condition.

---

## 2. HANDLING CAUTIONS

This chapter describes important cautions regarding how to handle the transmitter. Read carefully before using the transmitter.

The EJA Series pressure transmitters are thoroughly tested at the factory before shipment. When the transmitter is delivered, visually check them to make sure that no damage occurred during shipment.

Also check that all transmitter mounting hardware shown in Figure 2.1 is included. If the transmitter was ordered without the mounting bracket, the transmitter mounting hardware is not included. After checking the transmitter, repack it in the way it was delivered until installation.




Figure 2.1 Transmitter Mounting Hardware

### 2.1 Model and Specifications Check

The model name and specifications are indicated on the name plate attached to the case. If the *reverse* operating mode was ordered (reverse signal), 'REVERSE' will be inscribed in field \*1; if *square root* display mode was ordered, 'SQRT' is inscribed in field \*2.

|                    |        |               |                          |
|--------------------|--------|---------------|--------------------------|
| DPHARP TRANSMITTER |        | CAL RING      |                          |
| MODEL              | STYLE  | DISP MODE     | SQRT                     |
| SUFFIX             |        | OUTPUT MODE   | *2                       |
|                    |        | EX. PROOF     | Ex do IIC T4 X           |
| SUPPLY             | 24V DC | AMB. TEMP.    | 60°C PROCESS TEMP. 120°C |
| OUTPUT             | mA DC  | *1            | NO.                      |
| MWP                |        |               |                          |
| YOKOGAWA           |        | Made in Japan | N200                     |

Figure 2.2 Name Plate Example of JIS Flameproof Type

### 2.2 Unpacking

When moving the transmitter to the installation site, keep it in its original packaging. Then, unpack the transmitter there to avoid damage on the way.

### 2.3 Storage

The following precautions must be observed when storing the instrument, especially for a long period.

- (a) Select a storage area which meets the following conditions:
- It is not exposed to rain or water.
  - It suffers minimum vibration and shock.
  - It has an ambient temperature and relative humidity within the following ranges.

Ambient temperature:

–40 to 85°C without integral indicator

–30 to 80°C with integral indicator

Relative humidity:

5% to 100% R.H. (at 40°C)

Preferred temperature and humidity:

approx. 25°C and 65% R.H.

- (b) When storing the transmitter, repack it as nearly as possible to the way it was packed when delivered from the factory.

- (c) If storing a transmitter that has been used, thoroughly clean the chambers inside the cover flanges and integral flow orifice unit, so that no measured fluid remains in it. Also make sure before storing that the pressure-detector and transmitter section are securely mounted.

## 2.4 Selecting the Installation Location

The transmitter is designed to withstand severe environmental conditions. However, to ensure stable and accurate operation for years, observe the following precautions when selecting an installation location.

- (a) **Ambient Temperature**  
Avoid locations subject to wide temperature variations or a significant temperature gradient. If the location is exposed to radiant heat from plant equipments, provide adequate thermal insulation and/or ventilation.
- (b) **Ambient Atmosphere**  
Avoid installing the transmitter in a corrosive atmosphere. If the transmitter must be installed in a corrosive atmosphere, there must be adequate ventilation as well as measures to prevent intrusion or stagnation of rain water in conduits.
- (c) **Shock and Vibration**  
Select an installation site suffering minimum shock and vibration (although the transmitter is designed to be relatively resistant to shock and vibration).
- (d) **Installation of Explosion-protected Transmitters**  
Explosion-protected transmitters can be installed in hazardous areas according to the types of gases for which they are certified. See Subsection 2.9 "Installation of Explosion Protected Type Transmitters."

## 2.5 Pressure Connection



### WARNING

- Instrument installed in the process is under pressure. Never loosen the process connector bolts to avoid the dangerous spouting of process fluid.
- During draining condensate from the pressure-detector section, take appropriate care to avoid contact with the skin, eyes or body, or inhalation of vapors, if the accumulated process fluid may be toxic or otherwise harmful.

The following precautions must be observed in order to safely operate the transmitter under pressure.

- (a) Make sure that the four manifold bolts are tightened firmly.
- (b) Make sure that there are no leaks in the impulse piping.
- (c) Never apply a pressure higher than the specified maximum working pressure.

## 2.6 Waterproofing of Cable Conduit Connections

Apply a non-hardening sealant to the threads to waterproof the transmitter cable conduit connections. (See Figure 6.4.2a, 6.4.2b and 6.4.2d.)

## 2.7 Restrictions on Use of Radio Transceiver



### IMPORTANT

Although the transmitter has been designed to resist high frequency electrical noise, if a radio transceiver is used near the transmitter or its external wiring, the transmitter may be affected by high frequency noise pickup. To test for such effects, bring the transceiver in use slowly from a distance of several meters from the transmitter, and observe the measurement loop for noise effects. Thereafter, always use the transceiver outside the area affected by noise.

## 2.8 Insulation Resistance and Dielectric Strength Test

Since the transmitter has undergone insulation resistance and dielectric strength tests at the factory before shipment, normally these tests are not required. However, if required, observe the following precautions in the test procedures.

- (a) Do not perform such tests more frequently than is absolutely necessary. Even test voltages that do not cause visible damage to the insulation may degrade the insulation and reduce safety margins.
- (b) Never apply a voltage exceeding 500 V DC (100 V DC with an internal lightning protector) for the insulation resistance test, nor a voltage exceeding 500 V AC (100 V AC with an internal lightning protector) for the dielectric strength test.

(c) Before conducting these tests, disconnect all signal lines from the transmitter terminals. Perform the tests in the following procedure:

**• Insulation Resistance Test**

- 1) Short-circuit the + and – SUPPLY terminals in the terminal box.
- 2) Turn OFF the insulation tester. Then connect the insulation tester plus (+) lead wire to the shorted SUPPLY terminals and the minus (–) leadwire to the grounding terminal.
- 3) Turn ON the insulation tester power and measure the insulation resistance. The voltage should be applied short as possible to verify that the insulation resistance is at least 20 MΩ.
- 4) After completing the test and being very careful not to touch exposed conductors disconnect the insulation tester and connect a 100 kΩ resistor between the grounding terminal and the short-circuiting SUPPLY terminals. Leave this resistor connected at least one second to discharge any static potential. Do not touch the terminals while it is discharging.

**• Dielectric Strength Test**

- 1) Short-circuit the + and – SUPPLY terminals in the terminal box.
- 2) Turn OFF the dielectric strength tester. Then connect the tester between the shorted SUPPLY terminals and the grounding terminal. Be sure to connect the grounding lead of the dielectric strength tester to the ground terminal.
- 3) Set the current limit on the dielectric strength tester to 10 mA, then turn ON the power and gradually increase the test voltage from ‘0’ to the specified voltage.
- 4) When the specified voltage is reached, hold it for one minute.
- 5) After completing this test, slowly decrease the voltage to avoid any voltage surges.

## 2.9 Installation of Explosion Protected Type



**NOTE**

For FOUNDATION Fieldbus explosion protected type, please refer to IM 1C22T2-01E.



**WARNING**

To pressure the safety of explosionproof equipment requires great care during mounting, wiring, and piping. Safety requirements also place restrictions on maintenance and repair activities. Please read the following sections very carefully.

### 2.9.1 FM Approval

**a. FM Intrinsically Safe Type**

Caution for FM intrinsically safe type. (Following contents refer “DOC. No. IFM012-A12 P.1 and 2.”)

**Note 1.** Model EJA Series pressure transmitters with optional code /FS1 are applicable for use in hazardous locations.

- Intrinsically Safe for Class I, Division 1, Groups A, B, C & D. Class II, Division 1, Groups E, F & G and Class III, Division 1 Hazardous Locations.
- Nonincendive for Class I, Division 2, Groups A, B, C & D. Class II, Division 2, Groups E, F & G and Class III, Division 1 Hazardous Locations.
- Outdoor hazardous locations, NEMA 4X.
- Temperature Class: T4
- Ambient temperature: –40 to 60°C

**Note 2.** Entity Parameters

- Intrinsically Safe Apparatus Parameters [Groups A, B, C, D, E, F and G]  
 $V_{max} = 30\text{ V}$                        $C_i = 22.5\text{ nF}$   
 $I_{max} = 165\text{ mA}$                        $L_i = 730\text{ μH}$   
 $P_{max} = 0.9\text{ W}$

- \* Associated Apparatus Parameters (FM approved barriers)  
 $V_{oc} \leq 30\text{ V}$                        $C_a > 22.5\text{ nF}$   
 $I_{sc} \leq 165\text{ mA}$                        $L_a > 730\text{ μH}$   
 $P_{max} \leq 0.9\text{ W}$

- Intrinsically Safe Apparatus Parameters [Groups C, D, E, F and G]  
 $V_{max} = 30\text{ V}$                        $C_i = 22.5\text{ nF}$   
 $I_{max} = 225\text{ mA}$                        $L_i = 730\text{ μH}$   
 $P_{max} = 0.9\text{ W}$

- \* Associated Apparatus Parameters (FM approved barriers)  
 $V_{oc} \leq 30\text{ V}$                        $C_a > 22.5\text{ nF}$   
 $I_{sc} \leq 225\text{ mA}$                        $L_a > 730\text{ μH}$   
 $P_{max} \leq 0.9\text{ W}$

- Entity Installation Requirements  
 $V_{max} \geq V_{oc}$  or  $V_t$ ,  $I_{max} \geq I_{sc}$  or  $I_t$ ,  
 $P_{max} (\text{IS Apparatus}) \geq P_{max} (\text{Barrier})$   
 $C_a \geq C_i + C_{cable}$ ,  $L_a \geq L_i + L_{cable}$

**Note 3. Installation**

- Barrier must be installed in an enclosure that meets the requirements of ANSI/ISA S82.01.
- Control equipment connected to barrier must not use or generate more than 250 V rms or V dc.
- Installation should be in accordance with ANSI/ISA RP12.6 “Installation of Intrinsically Safe Systems for Hazardous (Classified) Locations” and the National Electric Code (ANSI/NFPA 70).
- The configuration of associated apparatus must be FMRC Approved.
- Dust-tight conduit seal must be used when installed in a Class II, III, Group E, F and G environments.
- Associated apparatus manufacturer’s installation drawing must be followed when installing this apparatus.
- The maximum power delivered from the barrier must not exceed 0.9 W.
- Note a warning label worded “SUBSTITUTION OF COMPONENTS MAY IMPAIR INTRINSIC SAFETY,” and “INSTALL IN ACCORDANCE WITH DOC. No. IFM012-A12 P.1 and 2.”

**Note 4. Maintenance and Repair**

- The instrument modification or parts replacement by other than authorized representative of Yokogawa Electric Corporation is prohibited and will void Factory Mutual Intrinsically safe and Nonincendive Approval.

**b. FM Explosionproof Type**

Caution for FM explosionproof type.

**Note 1.** Model EJA Series differential, gauge, and absolute pressure transmitters with optional code /FF1 are applicable for use in hazardous locations.

- Explosionproof for Class I, Division 1, Groups B, C and D.
- Dust-ignitionproof for Class II/III, Division 1, Groups E, F and G.
- Outdoor hazardous locations, NEMA 4X.
- Temperature Class: T6
- Ambient Temperature: -40 to 60°C
- Supply Voltage: 42 V dc max.
- Output signal: 4 to 20 mA

**Note 2. Wiring**


- All wiring shall comply with National Electrical Code ANSI/NEPA70 and Local Electrical Codes.
- When installed in Division 1, “FACTORY SEALED, CONDUIT SEAL NOT REQUIRED.”

**Note 3. Operation**

- Keep the “CAUTION” nameplate attached to the transmitter.
- CAUTION: OPEN CIRCUIT BEFORE REMOVING COVER. FACTORY SEALED, CONDUIT SEAL NOT REQUIRED. INSTALL IN ACCORDANCE WITH THE INSTRUCTION MANUAL IM 1C22.
- Take care not to generate mechanical sparking when accessing to the instrument and peripheral devices in a hazardous location.

**Note 4. Maintenance and Repair**

- The instrument modification or parts replacement by other than authorized representative of Yokogawa Electric Corporation is prohibited and will void Factory Mutual Explosionproof Approval.



**c. FM Intrinsically Safe Type/FM Explosionproof Type**

Model EJA Series pressure transmitters with optional code /FU1 can be selected the type of protection (FM Intrinsically Safe or FM Explosionproof) for use in hazardous locations.

**Note 1.** For the installation of this transmitter, once a particular type of protection is selected, any other type of protection cannot be used. The installation must be in accordance with the description about the type of protection in this instruction manual.

Note 2. In order to avoid confusion, unnecessary marking is crossed out on the label other than the selected type of protection when the transmitter is installed.

**2.9.2 CSA Certification**

**a. CSA Intrinsically Safe Type**

Caution for CSA Intrinsically safe type. (Following contents refer to “DOC No. ICS003-A12 P.1-1 and P.1-2.”)

Note 1. Model EJA Series differential, gauge, and absolute pressure transmitters with optional code /CS1 are applicable for use in hazardous locations


- Intrinsically Safe for Class I, Division 1, Groups A, B, C & D. Class II, Division 1, Groups E, F & G and Class III, Division 1 Hazardous Locations.
- Nonincendive for Class I, Division 2, Groups A, B, C & D, Class II, Division 2, Groups F & G, and Class III, Hazardous Locations. (not use Safety Barrier)
- Encl. “Type 4X”
- Temperature Class: T4
- Ambient temperature: -40 to 60°C
- Process Temperature: 120°C max.

Note 2. Entity Parameters

- Intrinsically safe ratings are as follows:
  - Maximum Input Voltage ( $V_{max}$ ) = 30 V
  - Maximum Input Current ( $I_{max}$ ) = 165 mA
  - Maximum Input Power ( $P_{max}$ ) = 0.9 W
  - Maximum Internal Capacitance ( $C_i$ ) = 22.5 nF
  - Maximum Internal Inductance ( $L_i$ ) = 730  $\mu$ H
- \* Associated apparatus (CSA certified barriers)
  - Maximum output voltage ( $V_{oc}$ )  $\leq$  30 V
  - Maximum output current ( $I_{sc}$ )  $\leq$  165 mA
  - Maximum output power ( $P_{max}$ )  $\leq$  0.9 W

Note 3. Installation

- All wiring shall comply with Canadian Electrical Code Part I and Local Electrical Codes.
- The instrument modification or parts replacement by other than authorized representative of Yokogawa Electric Corporation and Yokogawa Corporation of America is prohibited and will void Canadian Standards Intrinsically safe and nonincendive Certification.



**b. CSA Explosionproof Type**

Caution for CSA explosionproof type.

Note 1. Model EJA Series differential, gauge, and absolute pressure transmitters with optional code /CF1 are applicable for use in hazardous locations:

- Explosionproof for Class I, Division 1, Groups B, C and D.
- Dust-ignitionproof for Class II/III, Division 1, Groups E, F and G.
- Encl “Type 4X”
- Temperature Class: T6, T5, and T4
- Process Temperature: 85°C (T6), 100°C (T5), and 120°C (T4)
- Ambient Temperature: -40 to 80°C
- Supply Voltage: 42 V dc max.
- Output Signal: 4 to 20 mA

Note 2. Wiring

- All wiring shall comply with Canadian Electrical Code Part I and Local Electrical Codes.
- In hazardous location, wiring shall be in conduit as shown in the figure.

**CAUTION: SEAL ALL CONDUITS WITHIN 50 cm OF THE ENCLOSURE. UN SCÉLLEMENT DOIT ÊTRE INSTALLÉ À MOINS DE 50 cm DU BÎTIER.**

- When installed in Division 2, “SEALS NOT REQUIRED.”

Note 3. Operation

- Keep the “CAUTION” label attached to the transmitter.



CAUTION: OPEN CIRCUIT BEFORE REMOVING COVER.

OUVRIRE LE CIRCUIT AVANT D'ENLEVER LE COUVERCLE.

- Take care not to generate mechanical sparking when accessing to the instrument and peripheral devices in a hazardous location.

Note 4. Maintenance and Repair

- The instrument modification or parts replacement by other than authorized representative of Yokogawa Electric Corporation and Yokogawa Corporation of America is prohibited and will void Canadian Standards Explosionproof Certification.



c. CSA Intrinsically Safe Type/CSA Explosionproof Type

Model EJA Series pressure transmitters with optional code /CU1 can be selected the type of protection (CSA Intrinsically Safe or CSA Explosionproof) for use in hazardous locations.

Note 1. For the installation of this transmitter, once a particular type of protection is selected, any other type of protection cannot be used. The installation must be in accordance with the description about the type of protection in this instruction manual.

Note 2. In order to avoid confusion, unnecessary marking is crossed out on the label other than the selected type of protection when the transmitter is installed.

2.9.3 SAA Certification

a. SAA Intrinsically Safe Type

Caution for SAA Intrinsically safe type and Type n.

Note 1. Model EJA Series differential, gauge, and absolute pressure transmitters with optional code /SU1 are applicable for use in hazardous locations.

- Type of Protection and Marking Code: Ex ia IIC T4 (Tamb = 60°C) IP67 Class I Zone 0
- Type of Protection and Marking Code: Ex n IIC T4 (Tamb = 60°C) IP67 Class I Zone 2
- Ambient Temperature: -40 to 60°C

Note 2. Entity Parameters

- Intrinsically safe rating of the transmitters are as follows.


- Maximum Input Voltage (Ui) = 30 V
- Maximum Input Current (Ii) = 165 mA
- Maximum Input Power (Pi) = 0.9 W
- Maximum Internal Capacitance (Ci) = 0.02 μF
- Maximum Internal Inductance (Li) = 0.73 mH

Note 3. Wiring


- All Wiring shall comply with the Australian Standard.

Note 4. Maintenance and Repair

- The instrument modification or parts replacement by other than authorized representative of Yokogawa Electric Corporation is prohibited and will void Standards Association of Australia Intrinsically safe and Type n Certification.



\*1: Any safety barriers used for the output current must be limited by a resistor “R” such that  $I_{maxout} \cdot U_z / R$ .



\*2: The voltage of the power supply is not exceed 30V dc.

**b. SAA Flameproof Type**

Caution for SAA flameproof type.

Note 1. Model EJA Series differential, gauge, and absolute pressure transmitters with optional code /SU1 are applicable for use in hazardous locations:

- Type of Protection and marking Code: Ex d II C T\* IP67 Class I Zone 1 (T\* see schedule)
- Temperature Class: T6, T5, and T4
- Process Temperature: 85°C (T6), 100°C (T5), and 120°C (T4)
- Supply voltage: 42 V dc max.
- Output Signal: 4 to 20 mA
- Ambient Temperature: -40 to 80°C

Note 2. Wiring

- All wiring shall comply with the Australian Standard.

Note 3. Operation

- Keep the “CAUTION” label attached to the transmitter.

**CAUTION: AMBIENT TEMPERATURE ABOVE 75 DEG C SELECT SUITABLE CABLE. DISCONNECT POWER AND WAIT 1 MINUTE BEFORE REMAKING COVER**

- Take care not to generate mechanical sparking when accessing to the instrument and peripheral devices in a hazardous location.

Note 4. Maintenance and Repair

- The instrument modification or parts replacement by other than authorized representative of Yokogawa Electric Corporation is prohibited and will void Standards Association of Australia Flameproof Certification.

**2.9.4 CENELEC (KEMA)/IEC (KEMA) Certification**

**a. CENELEC (KEMA) Intrinsically Safe Type**

Caution for CENELEC (KEMA) intrinsically safe type.

Note 1. Model EJA Series differential, gauge, and absolute pressure transmitters with optional code /KS1 for potentially explosive atmospheres:

- Type of Protection and Marking code: EEx ia IIC T4
- Temperature Class: T4
- Process Temperature: 120°C max.
- Ambient Temperature: -40 to 60°C

Note 2. Electrical Data

- In type of explosion protection intrinsic safety EEx ia IIC only for connection to a certified intrinsically safe circuit with following maximum values:

$U_i = 30\text{ V}$

$I_i = 165\text{ mA}$

$P_i = 0.9\text{ W}$

Effective internal capacitance;  $C_i = 22.5\text{ nF}$


Effective internal inductance;  $L_i = 730\text{ }\mu\text{H}$

Note 3. Installation

- All wiring shall comply with local installation requirements. (Refer to the installation diagram)

Note 4. Maintenance and Repair

- The instrument modification or parts replacement by other than authorized representative of Yokogawa Electric Corporation is prohibited and will void KEMA Intrinsically safe Certification.



\*1: In any safety barriers used the output current must be limited by a resistor “R” such that  $I_{maxout} \leq U_z/R$ .

**b. CENELEC (KEMA) Flameproof Type**

Caution for CENELEC (KEMA) flameproof type.

Note 1. Model EJA Series differential, gauge, and absolute pressure transmitters with optional code /KF1 for potentially explosive atmospheres:

- Type of Protection and Marking Code: EEx d IIC T6...T4
- Temperature Class: T6, T5, and T4
- Maximum Process Temperature: 85°C (T6), 100°C (T5), and 120°C
- Ambient Temperature: -40 to 80°C

Note 2. Electrical Data

- Supply voltage: 42 V dc max.
- Output signal: 4 to 20 mA

Note 3. Installation

- All wiring shall comply with local installation requirement.
- The cable entry devices shall be of a certified flameproof type, suitable for the conditions of use.

**Note 4. Operation**

- Keep the “CAUTION” label to the transmitter.  
CAUTION: WAIT 1 MIN. AFTER POWER-DISCONNECTION, BEFORE OPENING THE ENCLOSURE.
- Take care not to generate mechanical sparking when accessing to the instrument and peripheral devices in a hazardous location.

**Note 5. Maintenance and Repair**

- The instrument modification or parts replacement by other than authorized representative of Yokogawa Electric Corporation is prohibited and will void KEMA Flameproof Certification.

**c. IEC (KEMA) Type of Protection “n”**

Caution for IEC (KEMA) Type of Protection “n.”

**Note 1. Model EJA Series pressure transmitters with optional code /KU1 for potentially explosive atmospheres.**

- Type of Protection and Marking Code:  
Ex nA IIC T4
- Temperature Class: T4
- Process Temperature: 120°C max.
- Ambient Temperature: -40 to 60°C

**Note 2. Electrical Data**


- Supply and output circuit  $\leq 30$  V dc, 165 mA (terminals + and -)

**Note 3. Installation**

- All wiring shall comply with local installation requirements. (refer to the installation diagram)

**Note 4. Maintenance and Repair**

- The instrument modification or parts replacement by other than authorized representative of Yokogawa Electric Corporation is prohibited and will void KEMA Type of Protection “n” Certification.



Ratings of the Power Supply as follows;

- Maximum Voltage: 30 V
- Maximum Current: 165 mA

**d. CENELEC (KEMA) Intrinsically Safe Type/ CENELEC (KEMA) Flameproof Type/IEC (KEMA) Type of Protection “n”**

Model EJA Series pressure transmitters with optional code /KU1 can be selected the type of protection (CENELEC (KEMA) Intrinsically Safe or CENELEC (KEMA) Flameproof or IEC (KEMA) Type of Protection “n”) for use in hazardous locations.

**Note 1.** For the installation of this transmitter, once a particular type of protection is selected, any other type of protection cannot be used. The installation must be in accordance with the description about the type of protection in this instruction manual.

**Note 2.** In order to avoid confusion, unnecessary marking is crossed out on the label other than the selected type of protection when the transmitter is installed.

**2.9.5 JIS Certification****JIS Flameproof and Intrinsically Safe Type**

The model EJA Series pressure transmitters with optional code /JF1 and /JS1, which have obtained certification according to technical criteria for explosion-protected construction of electric machinery and equipment (Standards Notification No. 556 from the Japanese Ministry of Labor) conforming to IEC standards, are designed for hazardous areas where explosive gases and/or inflammable vapors may be present. [JIS Flameproof Type (optional code /JF1) allows installation in Division 1 and 2 areas, and JIS Intrinsically Safe Type (optional code /JS1) allows installation in Division 0, 1, and 2 areas.]

To observe the safety of flameproof equipment requires great care during mounting, wiring, and piping. Safety requirements also place restrictions on maintenance and repair activities. Users absolutely must read “Installation and Operating Precautions for JIS Intrinsically Safe Equipment and Flameproof Equipment” at the end of this manual.

**CAUTION**

(For JIS flameproof type without integral indicator)

When the fill fluid near the sensor part moves from within, the instrument outputs a failure signal either high or low of the specific signal. In that case, generate the alarm to identify that the failure signal is output since the event may invalidate the flameproof approval. If the optional integral indicator is equipped, the indicator identifies the alarm on its display. Therefore, no other alarm generation is necessary.




Figure 2.3 Example of using DCS (Distributed Control System)

## 2.10 EMC Conformity Standards

For EMI (Emission): EN55011, AS/NZS 2064 1/2

For EMS (Immunity): EN50082-2

**NOTE**

YOKOGAWA recommends customer to apply the Metal Conduit Wiring or to use the twisted pair Shield Cable for signal wiring to conform the requirement of EMC Regulation, when customer installs the EJA Series Transmitters to the plant.

**CAUTION**

When selecting cables for JIS flameproof type transmitters, determine the cables' maximum allowable heat resistance depending on the process and ambient temperature condition on the transmitter as illustrated in Figure 2.4. Use cables having a maximum allowable heat resistance of at least 60°C for the transmitter in Region A and that of 75°C in Region B.






Figure 2.4 Selecting Cables

# 3. COMPONENT NAMES

## Vertical impulse piping type



## Horizontal impulse piping type



| Setting Pin (CN4) Position (Note 2) | Burn-Out Direction | Output at Burn-Out |
|-------------------------------------|--------------------|--------------------|
| H                                   | HIGH               | 110% or higher     |
| L                                   | LOW                | -5% or lower       |

F0301.EPS

Note 1: See Subsection 10.2, "Model and Suffix Codes," for details.

Note 2: Insert the pin (CN4) as shown in the figure above to set the burn-out direction. The pin is set to the H side for delivery (unless option code /C1 is specified in the order).

The setting can be confirmed by calling up parameter D52 using the BRAIN TERMINAL. Refer to Subsection 8.3.3 (10).

Figure 3.1 Component Names

Table 3.1 Display Symbol

| Display Symbol   | Meaning of Display Symbol   |
|--|---|
| $\sqrt{\quad}$   | Display mode is 'square root'. (Display is not lit when 'proportional' mode.) |
| ▲  | The output signal being zero-adjusted is increasing.                          |
| ▼  | The output signal being zero-adjusted is decreasing.                          |
| %, Pa, hPa, kPa, MPa, kgf/cm <sup>2</sup> , gf/cm <sup>2</sup> , mbar, bar, atm, mmHg, mmH <sub>2</sub> O, inH <sub>2</sub> O, inHg, ftH <sub>2</sub> O, psi, Torr | Select one of these seventeen available engineering units for the display.    |

T0301.EPS

# 4. INSTALLATION

## 4.1 Precautions

Before installing the transmitter, read the cautionary notes in Section 2.4, “Selecting the Installation Location.” For additional information on the ambient conditions allowed at the installation location, refer to Subsection 10.1 “Standard Specifications.”




### IMPORTANT

- When welding piping during construction, take care not to allow welding currents to flow through the transmitter.
- Do not step on this instrument after installation.


## 4.2 Mounting

- The transmitter can be mounted on a nominal 50 mm (2-inch) pipe using the mounting bracket supplied, as shown in Figure 4.2.1 and 4.2.2. The transmitter can be mounted on either a horizontal or a vertical pipe.
- When mounting the bracket on the transmitter, tighten the (four) bolts that hold the transmitter with a torque of approximately 39 N·m {4kgf·m}.
- The transmitter is shipped with the manifold set up as per the order specifications.
- For correct flow measurement, the flow path must always be filled with fluid; otherwise, measurement accuracy cannot be assured.
- For the vertical impulse piping type, it is recommended that the manifold be mounted facing up for liquid flow measurement; facing down for gas flow measurement, as shown in Figure 4.2.2.

Vertical pipe mounting




Horizontal pipe mounting




F0401.EPS

Figure 4.2.1 Transmitter Mounting (Horizontal Impulse Piping Type)

Vertical pipe mounting(Manifold upside)



Vertical pipe mounting(Manifold downside)



F0402.EPS

Figure 4.2.2 Transmitter Mounting (Vertical Impulse Piping Type)

### 4.3 Rotating Transmitter Section

The DPharp transmitter section can be rotated in 90° segments.

- 1) Remove the two Allen screws that fasten the transmitter section and capsule assembly, using the Allen wrench.
- 2) Rotate the transmitter section slowly in 90° segments.
- 3) Tighten the two Allen screws to a torque of 5 N·m.




#### IMPORTANT

Do not rotate the transmitter section more than 180°.

#### Vertical impulse pipe


Pressure-detector section



#### Horizontal impulse pipe

Transmitter section

Rotate 90° or 180° segments



F0403.EPS

Figure 4.3 Rotating Transmitter Section

# 5. INSTALLING IMPULSE PIPING

## 5.1 Process Piping Installation Precautions

The manifold contains a small-bore orifice. For the transmitter of a high pressure connection right side, the orifice is placed facing such a direction as to enable normal flow measurement when fluid is flowed from right to left (as viewed from the front). If the orifice is removed from the manifold, it must be replaced facing the correct direction. (For disassembly and reassembly procedures, see Subsection 9.4.4)

Pay careful attention to the following points when routing the process piping and connection the process piping to the transmitter.

### 5.1.1 Connecting Process Piping to the Transmitter

#### (1) Confirming the Process Fluid Flow Direction (Figure 5.1.1)

The mark “←” on the manifold indicates the direction in which the process fluid is flowed (from right to left). When connecting the process piping to the process connector, confirm the process fluid flow direction.




Figure 5.1.1 Manifold and Flow Direction Indication

#### (2) Tightening the Process Connector Mounting Bolts

The transmitter is shipped with the process connector mounting bolts only loosely tightened. After connecting the process piping, tighten these bolts uniformly to prevent leaks.

#### (3) Removing the Process Connector Port Dustproof Cap

The process connector port threads are covered with a plastic cap to exclude dust. This cap must be removed before connecting the piping. (Be careful not to damage the threads when removing this cap. Never insert a screwdriver or other tool between the cap and port threads to remove the cap.)

### 5.1.2 Routing the Process Piping

#### (1) Relationship between Process Fluid and Manifold Locations (For the vertical impulse piping type)

If condensate (or gas) generated in the process piping were allowed to accumulate, then it would be necessary to remove it periodically by opening the drain (or vent) plug. However, this would generate a transient disturbance in the pressure measurement. Therefore, the process piping must be routed so that any condensate (or gas) generated in the process piping will not accumulate in the pressure-sensing assembly of the transmitter.



#### NOTE


- If the process fluid is a gas, then as a rule the manifold must be located at the downside of the pressure-sensing assembly. (Figure 5.1.2)
- If the process fluid is a liquid, then as a rule the manifold must be located at the upside of the pressure-sensing assembly. (Figure 5.1.3)

**(2) Pipe Size for Process Piping**

Use a 15 mm (1/2-inch) pipe for process piping connection to the process connector.


**(3) Preventing Freezing**

If there is any risk that the process fluid in the transmitter pressure-sensing assembly could freeze, use a steam jacket or heater to maintain the temperature of the fluid.



F0502.EPS

**Figure 5.1.2 Manifold Location at the Downside (for Gas Flow Measurement)**



F0503.EPS


**Figure 5.1.3 Manifold Location at the Upside (for Liquid Flow Measurement)**

**5.2 Process Piping Connection Examples**

Figure 5.2 shows examples of typical process piping connections. Before connecting the transmitter to the process, study the transmitter installation location, the process piping layout, and the characteristics of the process fluid (corrosiveness, toxicity, flammability, etc.), in order to make appropriate changes and additions to the connection configurations.

Note the following points when referring to these piping examples.

- The high pressure connecting port on the transmitter is shown on the right (as viewed from the front).
- The transmitter process piping connection is shown for a vertical impulse piping connection configuration in which the direction of process flow is from right to left.
- The process piping material used must be compatible with the process pressure, temperature, and other conditions.
- A variety of process piping-mounted stop valves are available according to the type of connection (flanged, screwed, welded), construction (globe, gate, or ball valve), temperature and pressure. Select the type of valve most appropriate for the application.



**Figure 5.2 Process Piping Connection Examples**

F0504.EPS

# 6. WIRING

## 6.1 Wiring Precautions



### IMPORTANT

- Lay wiring as far as possible from electrical noise sources such as large capacity transformers, motors, and power supplies.
- Remove electrical connection dust cap before wiring.
- All threaded parts must be treated with waterproofing sealant. (A non-hardening silicone group sealant is recommended.)
- To prevent noise pickup, do not pass signal and power cables through the same ducts.
- Explosion-protected instruments must be wired in accordance with specific requirements (and, in certain countries, legal regulations) in order to preserve the effectiveness of their explosion-protected features.
- The terminal box cover is locked by an Allen head bolt (a shrouding bolt) on CENELEC, SAA, and JIS flameproof type transmitters. When the shrouding bolt is driven clockwise by an Allen wrench, it is going in and cover lock is released, and then the cover can be opened. See Subsection 9.4 “Disassembly and Reassembly” for details.

Refer to The “Installation and Operating Precautions for JIS Flameproof Equipment” and “Installation and Operating Precautions for JIS Intrinsically Safe Equipment” at the end of this manual for correct wiring.

## 6.2 Selecting the Wiring Materials

- Use stranded leadwires or cables which are the same as or better than 600 V grade PVC insulated wire (JIS C3307) or equivalent.
- Use shielded wires in areas that are susceptible to electrical noise.
- In areas with higher or lower ambient temperatures, use appropriate wires or cables.



### CAUTION


When selecting cables for JIS flameproof type transmitters, determine cables' maximum allowable heat resistance depending on the temperature condition on the transmitter. See Section 2.9.5 JIS Certification for details.

- In environment where oils, solvents, corrosive gases or liquids may be present, use wires or cables that are resistant to such substances.
- It is recommended that crimp-on solderless terminal lugs (for 4 mm screws) with insulating sleeves be used for leadwire ends.

## 6.3 Connections of External Wiring to Terminal Box

### 6.3.1 Power Supply Wiring Connection

Connect the power supply wiring to the SUPPLY + and – terminals.




F0601.EPS

Figure 6.3.1 Power Supply Wiring Connection

### 6.3.2 External Indicator Connection

Connect wiring for external indicators to the CHECK + and – terminals.

(Note) Use an external indicator whose internal resistance is 10 Ω or less.



F0602.EPS

Figure 6.3.2 External Indicator Connection

### 6.3.3 BRAIN TERMINAL BT200 Connection

Connect the BT200 to the SUPPLY + and – terminals (Use hooks).




Figure 6.3.3 BT200 Connection

### 6.3.4 Check Meter Connection

Connect the check meter to the CHECK + and – terminals (use hooks).

- A 4 to 20 mA DC output signal from the CHECK + and – terminals.

(Note) Use a check meter whose internal resistance is 10  $\Omega$  or less.




Figure 6.3.4 Check Meter Connection

## 6.4 Wiring



### CAUTION

For the intrinsically safe equipment and flameproof equipment, wiring materials and wiring work for these equipment including peripherals are strictly restricted. Users absolutely must read “Installation and Operating Precautions for JIS Intrinsically Safe Equipment” and “Installation and Operating Precautions for JIS Flameproof Equipment” at the end of this manual prior to the work.

### 6.4.1 Loop Configuration

Since the DPharp uses a two-wire transmission system, signal wiring is also used as power wiring.

DC power is required for the transmitter loop. The transmitter and distributor are connected as shown below.

For details of the power supply voltage and load resistance, see Section 6.6; for communications line requirements, see Subsection 8.1.2.

#### (1) General-use Type and Flameproof Type




Figure 6.4.1a Connection between Transmitter and Distributor

#### (2) Intrinsically Safe Type

For intrinsically safe type, a safety barrier must be included in the loop.





Figure 6.4.1b Connection between Transmitter and Distributor

## 6.4.2 Wiring Installation

### (1) General-use Type and Intrinsically Safe Type

Make cable wiring using metallic conduit or waterproof glands.

- Apply a non-hardening sealant to the terminal box connection port and to the threads on the flexible metal conduit for waterproofing.




F0607.EPS

Figure 6.4.2a Typical Wiring Using Flexible Metal Conduit

### (2) Flameproof Type (JIS)

Wire cables through a flameproof packing adapter, or using a flameproof metal conduit.

- Wiring cable through flameproof packing adapter for only JIS flameproof type (see Figure 6.4.2b).
- Use only flameproof packing adapters approved by Yokogawa.
- Apply a nonhardening sealant to the terminal box connection port and to the threads on the flameproof packing adapter for waterproofing.



F0608.EPS

Figure 6.4.2b Typical Cable Wiring Using Flameproof Packing Adapter

- Measure the cable outer diameter in two directions to within 1 mm.
- Calculate the average of the two diameters, and use packing with an internal diameter nearest to this value (see Table 6.4.2).


Table 6.4.2 Flameproof Packings and Applicable Cable Outer Diameters

| Optional Code | Wiring Port Thread Diameter | Applicable Cable OD (mm) | Identifying Mark | Part Number |
|---------------|-----------------------------|--------------------------|------------------|-------------|
| G11           | G 1/2                       | 8 to 10                  | 16 8-10          | G9601AM     |
| G12           |                             | 10.1 to 12               | 16 10-12         |             |

T0601.EPS

- Mounting flameproof packing adapter body to conduit connection (see Figure 6.4.2c)

- 1) Screw the flameproof packing adapter into the terminal box until the O-ring touches the wiring port (at least 6 full turns), and firmly tighten the lock nut.
- 2) Insert the cable through the union cover, the union coupling, the clamp nut, the clamp ring, the gland, the washer, the rubber packing, and the packing box, in that order.
- 3) Insert the end of the cable into the terminal box.
- 4) Tighten the union cover to grip the cable. When tightening the union cover, tighten approximately one turn past the point where the cable will no longer move up and down. Proper tightening is important. If it is too tight, a circuit break in the cable may occur; if not tight enough, the flameproof effectiveness will be compromised.
- 5) Fasten the cable by tightening the clamp nut.
- 6) Tighten the lock nut on the union cover.
- 7) Connect the cable wires to each terminal.



F0609.EPS

Figure 6.4.2c Installing Flameproof Packing Adapter

■ Flameproof metal conduit wiring

- A seal fitting must be installed near the terminal box connection port for a sealed construction.
- Apply a non-hardening sealant to the threads of the terminal box connection port, flexible metal conduit and seal fitting for waterproofing.




Figure 6.4.2d Typical Wiring Using Flameproof Metal Conduit

## 6.5 Grounding

- (a) Grounding should satisfy JIS Class 3 requirements (grounding resistance, 100 Ω or less). Grounding is required for JIS flameproof type and intrinsically safe type.

(Note) If equipped with built-in Lightning Protector, grounding should satisfy Special JIS class 3 requirements (grounding resistance, 10 Ω or less).

- (b) There are ground terminals on the inside and outside of the terminal box. Either of these terminals may be used.
- (c) Use 600 V grade PVC insulated wires for grounding.

Transmitter terminal box




Figure 6.5 Ground Terminals

## 6.6 Power Supply Voltage and Load Resistance

When configuring the loop, make sure that the external load resistance is within the range in the figure below.

(Note) In case of an intrinsically safe transmitter, external load resistance includes safety barrier resistance.




Figure 6.6 Relationship between Power Supply Voltage and External Load Resistance

# 7. OPERATION

## 7.1 Preparation for Starting Operation

The Model EJA115 low flow transmitter measures the flow rates of liquids and gases. This section describes the operation procedure for the EJA115 as shown in Figure 7.1 (vertical impulse piping type, high-pressure connection: right side) when measuring a liquid flow rate.

- (a) Follow the procedures below to introduce process pressure into the transmitter.
    - 1) Open the stop valve on the downstream side.
    - 2) Gradually open the stop valve on the upstream side to introduce process fluid into the transmitter pressure-detector section.
- This will cause process fluid to flow into the orifice built in the manifold, and apply flow-dependent differential pressure to the high and low pressure sides of the transmitter.

- 3) Confirm that there are no pressure leaks in the stop valves on the upstream and downstream sides, process piping connection or transmitter, etc.

### Venting Gas from the Transmitter Pressure-detector Section

- Since the piping in the example of Figure 7.1 is constructed to be self-venting, no venting operation is required. If it is not possible to make the piping self-venting, refer to Subsection 7.6 for instructions.

- (b) Turn ON power and connect the BT200.

Open the terminal box cover, and connect the BT200 to the SUPPLY + and – terminals.

- (c) Using the BT200, confirm that the transmitter is operating properly. Check parameter values or change the setpoints as necessary. See Chapter 8 for BT200 operation.

If the transmitter is equipped with an integral indicator, its indication can be used to confirm that the transmitter is operating properly.





Figure 7.1 Liquid Flow Measurement


### ■ Confirming that Transmitter is Operating Properly

#### Using the BT200

- If the wiring system is faulty, 'communication error' appears on the display.
- If the transmitter is faulty, 'SELF CHECK ERROR' appears on the display.



Communication error  
(Faulty wiring)



Self-diagnostic error  
(Faulty transmitter)

F0702.EPS

#### Using the integral indicator

- If the wiring system is faulty, the display stays blank.
- If the transmitter is faulty, an error code will appear on the display according to the nature of the error.



Self-diagnostic error on  
the integral indicator  
(Faulty transmitter)

F0703.EPS

 **NOTE**

If any of the error indications above appears on the display of the integral indicator or BT200, refer to Subsection 8.5.2 for corrective action.

**Verify and Change Transmitter Parameter Setting and Values**

The following parameters are the minimum settings required for operation. The transmitter has been shipped with these parameters. To confirm or change the values, see Subsection 8.3.3.

- Measuring range ..... See Subsection 8.3.3 (2)
- Output/integral indicator mode ..... See Subsection 8.3.3 (4)
- Operation mode ..... See Subsection 8.3.3 (9)

**7.2 Zero Point Adjustment**

Adjust the zero point after operating preparation is completed. Make sure to close the stop valves on the upstream and downstream sides before the adjustment.


 **IMPORTANT**

Do not turn off the power to the transmitter immediately after a zero adjustment. Powering off within 30 seconds after a zero adjustment will return the adjustment back to the previous settings.

The zero point adjustment can be made in either way: using the zero-adjustment screw of the transmitter or the BT200 operation.


For output signal checking, display the parameter **A10: OUTPUT (%)** in the BT200.

●BT200



Output signal (%) display

●Zero-adjustment Screw



F0704.EPS

**Using the Transmitter Zero-adjustment Screw**


Before adjusting a screw, check that the parameter **J20: EXT ZERO ADJ** displays **ENABLE**. See Subsection 8.3.3 (13) for the setting procedure.

Use a slotted screwdriver to turn the zero-adjustment screw. Turn the screw clockwise to increase the output or counterclockwise to decrease the output. The zero point adjustment can be made with a resolution of 0.01% of the setting range. Since the degree of zero adjustments varies with the screw turning speed, turn the screw slowly for fine adjustment and quickly for coarse adjustment.

**Using the BT200**

Zero point can be adjusted by simple key operation of the BT200.

Select parameter **J10: ZERO ADJ**, and press the **ENTER** key twice. The zero point will be adjusted automatically to the output signal 0% (4 mA DC). Confirm that the setting value displayed for the parameter is '0.0%' before pressing the **ENTER** key. See Subsection 8.3.3 (13) for BT200 operating procedures.



A display when parameter J10 is selected. Press **ENTER** key twice for 0% output 4 mA DC.

F0705.EPS

## 7.3 Starting Operation

After completing the zero point adjustment, follow the procedure below to start operation.

- 1) Open the stop valve on the upstream side.
- 2) Gradually open the stop valve on the downstream side. This places the transmitter in an operational condition.
- 3) Confirm the operating status. If the output signal exhibits wide fluctuations (hunting) due to periodic variation in the process pressure, use BT200 to dampen the transmitter output signal. Confirm the hunting using a receiving instrument or the integral indicator, and set the optimum damping time constant. See Subsection 8.3.3 (3), "Damping Time Constant Setup."
- 4) After confirming the operating status, perform the following.



### IMPORTANT

- Remove the BT200 from the terminal box, and confirm that none of the terminal screws are loosened.
- Close the terminal box cover and the amplifier cover. Screw each cover in tightly until it will not turn further.
- Two covers are required to be locked on the CENELEC, SAA, and JIS Flameproof type transmitters. An Allen head bolts (shrouding bolts) are provided under edge of the each cover for locking. When a shrouding bolts are driven counterclockwise by an Allen wrench, it is coming out and locks up a cover. (See page 9-3) After locking, the covers should be confirmed not to be opened.
- Tighten the zero-adjustment cover mounting screw to fix the cover in position.

## 7.4 Shutting Down Operation

Shut down the transmitter operation as follows.

- 1) Turn off the power.
- 2) Close the stop valves on the up and downstream sides.



### NOTE

Whenever shutting down the transmitter for a long period, remove any process fluid from the transmitter pressure-detector section.

## 7.5 Transmitter Measurement Range (Determining Differential Pressure Range)

The following describes the procedure for calculating the differential pressure range and the calculation example in low flow measurement.

Conversion factor in pressure unit:

$$1 \text{ Pa} = 1.01972 \times 10^{-1} \text{ mmH}_2\text{O}$$

$$1 \text{ mmH}_2\text{O} = 9.80665 \text{ Pa}$$

$$1.03323 \text{ kgf/cm}^2 = 1.01325 \times 10^2 \text{ kPa}$$

### 7.5.1 Determining the Differential Pressure Range

Use the following procedures to determine a differential pressure range according to the fluid conditions being measured.

- (a) Calculate a water or air equivalent flow from the flow of the fluid being measured (100% flow).

#### ■ Equivalent Water Flow Calculation

$$Q_w = 0.03162 \cdot Q_f \cdot \sqrt{\gamma_f} \quad \text{..... (1)}$$

Where,  $Q_w$ : Water equivalent volumetric flow ( $\text{m}^3/\text{h}$ ) at  $4^\circ\text{C}$ , 1 atm

$Q_f$ : Volumetric liquid flow ( $\text{m}^3/\text{h}$ ) at operating conditions ( $t^\circ\text{C}$ ,  $\text{p}\text{kgf/cm}^2\text{G}$ )

$\gamma_f$ : Specific liquid weight ( $\text{kgf/m}^3$ ) at operating conditions ( $t^\circ\text{C}$ ,  $\text{p}\text{kgf/cm}^2\text{G}$ )

### ■ Equivalent Air Flow Calculation

$$Q_o = 0.05409 \cdot Q_n \sqrt{\gamma_n \cdot \frac{273.15 + t}{1.0332 + p} \cdot \frac{Z_f}{Z_n}} \quad (2)$$

Where,  $Q_o$ : Air equivalent volumetric flow at 0°C,  
1 atm (Nm<sup>3</sup>/h)

$Q_n$ : Volumetric gas flow at 0°C, 1 atm (Nm<sup>3</sup>/h)

$\gamma_n$ : Specific gas weight at 0°C, 1 atm (kgf/Nm<sup>3</sup>)

$Z_n$ : Compression factor of gas at 0°C, 1 atm

$Z_f$ : Compression factor of gas at operations conditions (t°C, p kgf/cm<sup>2</sup>G)

- (b) Obtain a differential pressure from the above equivalent water or air flow using the nomograph shown in Figure 7.5.1 or 7.5.2. In this procedure, multiply  $Q_w$  or  $Q_o$  by 1000/60 to convert the flow unit into litre/min.
- (c) Select an orifice bore, taking into considerations pressure loss, etc.
- (d) As necessary, calculate Reynolds number at normal flow rate and correct the differential pressure obtained from the procedure (b).

### ■ Reynolds Number Calculation

$$Re = 354 \frac{W}{D \cdot \mu} \quad (3)$$

Where,  $Re$ : Reynolds number at normal flow rate

$W$ : Weight flow at normal flow rate (kgf/h) <sup>(Note)</sup>

$D$ : Orifice bore (mm)

$\mu$ : Viscosity (cP)

Note: Determination of  $W$

· For liquid,  $W = Q_f \cdot \gamma_f$

· For gas,  $W = Q_n \cdot \gamma_n$

### ■ Differential Pressure Correction using Reynolds Number

$$\Delta P = \left( \frac{1}{K_{af}/K_a} \right)^2 \cdot \Delta P_0$$

Where,  $\Delta P$ : Corrected differential pressure

$\Delta P_0$ : Differential pressure obtained from procedure (b)

$K_{af}/k_a$ : Correction factor obtained from Figure 7.5.3

For details concerning determination of differential pressure correction using Reynolds number, pressure loss, etc., refer to TI 6P1E2-01E.

F0713.EPS

### 7.5.2 Example of Calculation

|                   |   |
|-------------------|---|
| Fluid:            | N <sub>2</sub> gas (Nitrogen gas)                         |
| Flow range:       | 0 to 25 Nm <sup>3</sup> /h (flow rate at 0°C, 1 atm)      |
| Normal flow rate: | 18 Nm <sup>3</sup> /h                                     |
| Specific weight:  | 1.251 kgf/Nm <sup>3</sup> (specific weight at 0°C, 1 atm) |
| Temperature:      | 30°C  |
| Pressure:         | 1 kgf/cm <sup>2</sup>                                     |
| Viscosity:        | 0.018 cP  |

F0714.EPS

From Equation (2), air equivalent volumetric flow  $Q_o$  is:


$$Q_o = 0.05409 \times 25 \sqrt{1.251 \times \frac{273.15 + 30}{1.0332 + 1}} = 18.5 \text{ Nm}^3/\text{h} = 308.3 \text{ NI/min}$$

A differential pressure range of 0 to 2400 mmH<sub>2</sub>O is obtained from Figure 7.5.2 applying an orifice bore of 6.350 mm (where,  $Z_f/Z_n=1$  is assumed).

From Equation (3), Reynolds number at normal flow rate  $Re$  is:


$$Re = 354 \times \frac{18 \times 1.251}{6.35 \times 0.018} = 6.97 \times 10^4$$

Since the correction factor (1.00) is constant at this Reynolds number, no differential pressure correction is required. Consequently, the differential pressure range is determined as 0 to 2400 mmH<sub>2</sub>O.




F0707.EPS

Figure 7.5.1 Relationship between Equivalent Water Flow and Differential Pressure



F0708.EPS

Figure 7.5.2 Relationship between Equivalent Air Flow and Differential Pressure



| Characteristic curve | Orifice bore(mm) |
|----------------------|------------------|
| A                    | 0.508            |
| B                    | 0.864            |
| C                    | 1.511            |
| D                    | 2.527            |
| E                    | 4.039            |
| F                    | 6.350            |

F0709.EPS

Figure 7.5.3 Relationship between Reynolds Number and Correction Factor

## 7.6 Venting or Draining Transmitter Pressure-detector Section

Since this transmitter is designed to be self-draining and self-venting with vertical impulse piping connections, neither draining nor venting will be required if the impulse piping is configured appropriately for self-draining or self-venting operation.

If condensate (or gas) collects in the transmitter pressure-detector section, the measured pressure may be in error. If it is not possible to configure the piping for self-draining (or self-venting) operation, you will need to loosen the drain (vent) screw on the transmitter to completely drain (vent) any stagnated liquid (gas).

However, since draining condensate or bleeding off gas gives the pressure measurement disturbance, this should not be done when the loop is in operation.




### WARNING

Since the accumulated liquid (or gas) may be toxic or otherwise harmful, take appropriate care to avoid contact with the body, or inhalation of vapors.

### 7.6.1 Draining Condensate

- 1) Gradually open the drain screw or drain plug and drain the transmitter pressure-detector section. (See Figure 7.6.1.)
- 2) When all accumulated liquid is completely removed, close the drain screw or drain plug.
- 3) Tighten the drain screw to a torque of 10 N·m, and the drain plug to a torque of 34 to 39 N·m.




When you loosen the drain screw or drain plug, the accumulated liquid will be expelled in the direction on the arrow.

F0710.EPS

Figure 7.6.1 Draining the Transmitter

### 7.6.2 Venting Gas

- 1) Gradually open the vent screw to vent gas from the transmitter pressure-detector section. (See Figure 7.6.2.)
- 2) When the transmitter is completely vented, close the vent screw.
- 3) Tighten the vent screw to a torque of 10 N·m.



When you loosen the vent screw, the gas escapes in the direction of the arrow.

F0711.EPS

Figure 7.6.2 Venting the Transmitter

## 7.7 Setting the Range Using the Range-setting Switch

With actual pressure being applied to the transmitter, the range-setting switch (push-button) located on the optional integral indicator plate and the external zero-adjustment screw allow users to change (re-range) the low- and high-limit values for the measurement range (LRV and HRV) without using BT200. However, other changes in the display settings (scale range and engineering unit) for the integral indicator requires BT200.

Follow the procedure below to change the LRV and HRV settings.

[Example]

Rerange LRV to 0 and HRV to 20 kPa.

- 1) Connect the transmitter and apparatus as shown in Figure 9.3.1 and warm up for at least five minutes.
- 2) Press the range-setting push-button.  
The integral indicator then displays “LSET.”
- 3) Apply a pressure of 0 kPa (atmospheric pressure) to the transmitter. <sup>(Note 1)</sup>
- 4) Turn the external zero-adjustment screw in the desired direction. The integral indicator displays the output signal in %. <sup>(Note 2)</sup>
- 5) Adjust the output signal to 0% (1 V DC) by rotating the external zero-adjustment screw. Doing so completes the LRV setting.

- 6) Press the range-setting push-button. The integral indicator then displays “HSET.”
- 7) Apply a pressure of 20 kPa to the transmitter. <sup>(Note 1)</sup>
- 8) Turn the external zero-adjustment screw in the desired direction. The integral indicator displays the output signal in %. <sup>(Note 2)</sup>
- 9) Adjust the output signal to 100% (5 V DC) by rotating the external zero-adjustment screw. Doing so completes the HRV setting.
- 10) Press the range-setting push-button. The transmitter then switches back to the normal operation mode with the measurement range of 0 to 20 kPa.

Note 1: Wait until the pressure inside the pressure-detector section has stabilized before proceeding to the next step.

Note 2: If the pressure applied to the transmitter exceeds the previous LRV (or HRV), the integral indicator may display error number “Er.07” (In this case, the output signal percent and “Er.07” are displayed alternately every two seconds). Although “Er.07” is displayed, you may proceed to the next step. However, should any other error number be displayed, take the appropriate measure in reference to Subsection 8.5.2, “Errors and Countermeasures.”



### IMPORTANT

- Do not turn off the power to the transmitter immediately after completion of the change in the LRV and/or HRV setting(s). Note that powering off within thirty seconds after setting will cause a return to the previous settings.
- Changing LRV automatically changes HRV to the following value.

HRV = previous HRV + (new LRV – previous LRV)

- If the range-setting push-button and external zero-adjustment screw are not touched during a range-change operation, the transmitter automatically switches back to the normal operation mode.




Figure 7.7 Range-setting Switch

# 8. BRAIN TERMINAL BT200 OPERATION

The DPharp is equipped with BRAIN communications capabilities, so that range changes, Tag No. setup, monitoring of self-diagnostic results, and zero point adjustment can be handled by remote control via BT200 BRAIN TERMINAL or CENTUM CS console. This section describes procedures for setting parameters using the BT200. For details concerning the BT200, see IM 1C0A10-E, "BT200 User's Manual."

## 8.1 BT200 Operation Precautions

### 8.1.1 Connecting the BT200

Connection to the transmitter with the BT200 can be made by either connecting to the BT200 connection hooks in the transmitter terminal box or by connecting to a relaying terminal board.




Figure 8.1.1 Connecting the BT200

### 8.1.2 Conditions of Communication Line




Figure 8.1.2 Conditions of Communication Line

## 8.2 BT200 Operating Procedures

### 8.2.1 Key Layout and Screen Display

Figure 8.2.1a shows the arrangement of the operating keys on the BT200 keypad, and Figure 8.2.1b shows the BT200 screen component.




Figure 8.2.1a BT200 Key Layout





Figure 8.2.1b BT200 Screen Component

### 8.2.2 Operating Key Functions

#### (1) Alphanumeric Keys and Shift Keys

You can use the alphanumeric keys in conjunction with the shift keys to enter symbols, as well as alphanumeric keys.



F0805.EPS

#### a. Entering Digits, Symbols, and Spaces


Simply press the alphanumeric keys.

| Entry | Key-in Sequence |
|-------|-----------------|
| -4    |                 |
| 0.3   |                 |
| 1 -9  |                 |

T0801.EPS

#### b. Entering Letters (A through Z)

Press an alphanumeric key following a shift key to enter the letter shown on that side which the shift key represents. You must press the shift key before entering each letter.




F0806.EPS

| Entry | Key-in Sequence |
|-------|-----------------|
| W     |                 |
| IC    |                 |
| J. B  |                 |

T0802.EPS

Use the function key [F2] CAPS to select between uppercase and lowercase (for letters only). The case toggles between uppercase and lowercase each time you press [F2] CAPS.



F0807.EPS

Use the function key [F1] CODE to enter symbols. The following symbols will appear in sequence, one at a time, at the cursor each time you press [F1] CODE:

/ . - , + \* ) ( ' & % \$ # " !


To enter characters next to these symbols, press [ > ] to move the cursor.

| Entry | Key-in Sequence                         |
|-------|---|
| /m    | symbol command<br><br>( l ) ( / ) ( m ) |

T0803.EPS

#### (2) Function Keys

The functions of the function keys depend on the function commands on display.



F0808.EPS


#### Function Command List

| Command   | Function  |
|-----------|---|
| ADJ       | Displays the ADJ menu                           |
| CAPS/caps | Selects uppercase or lowercase                  |
| CODE      | Selects symbols                                 |
| CLR       | Erases input data or deletes all data           |
| DATA      | Updates parameter data                          |
| DEL       | Deletes one character                           |
| DIAG      | Calls the self-check panel                      |
| ESC       | Returns to the most recent display              |
| HOME      | Displays the menu panel                         |
| NO        | Quits setup and returns to the previous display |
| OK        | Proceeds to the next panel                      |
| PARM      | Enters the parameter number setup mode          |
| SET       | Displays the SET menu                           |
| SLOT      | Returns to the slot selection panel             |
| UTIL      | Calls the utility panel                         |
| *COPY     | Prints out parameters on display                |
| *FEED     | Paper feed                                      |
| *LIST     | Lists all parameters in the menu                |
| *PON/POFF | Automatic printout mode on or off               |
| *PRNT     | Changes to the print mode                       |
| *GO       | Starts printing                                 |
| *STOP     | Cancels printing                                |

\* Available on BT200-P00 (with printer).

T0804.EPS

### 8.2.3 Calling Up Menu Addresses Using the Operating Keys



F0809.EPS

## 8.3 Setting Parameters Using the BT200

### 8.3.1 Parameter Summary

Instruments to which applicable:

F: Differential pressure transmitters EJA110, EJA120, EJA118W, EJA118N, EJA118Y, and EJA115

P: Pressure transmitters EJA310, EJA430, EJA438W, and EJA438N

L: Liquid level transmitters EJA210 and EJA220

| No. | Item         | Description                              | Rewritability | Remarks  | Default Value  | Applicability |   |   |
|-----|--------------|--|---------------|--|--|---------------|---|---|
|     |              |  |               |  |  | F             | P | L |
| 01  | MODEL        | Model+capsule type                       | –             |  |  | ○             | ○ | ○ |
| 02  | TAG NO.      | Tag number                               | –             | 16 alphanumerics   |  | ○             | ○ | ○ |
| 03  | SELF CHECK   | Self-diagnostic result                   | –             | GOOD/ERROR   |  | ○             | ○ | ○ |
| A   | DISPLAY      | Measured data display                    | –             | Menu name  |  | ○             | ○ | ○ |
| A10 | OUTPUT (%)   | Output (in %)                            | –             | –5 to 110%   |  | ○             | ○ | ○ |
| A11 | ENGR. OUTPUT | Output (in engineering units)            | –             | –19999 to 19999  |  | ○             | ○ | ○ |
| A20 | AMP TEMP     | Amplifier temperature                    | –             | Unit specified in D30  |  | ○             | ○ | ○ |
| A21 | CAPSULE TEMP | Capsule temperature                      | –             | Unit specified in D30  |  | ○             | ○ | ○ |
| A30 | STATIC PRESS | Static pressure                          | –             | Unit specified in D31*   |  | ○             | – | ○ |
| A40 | INPUT        | Input (indicated in engineering DP unit) | –             | –32000 to 32000  |  | ○             | ○ | ○ |
| A60 | SELF CHECK   | Self-diagnostic messages                 | –             | GOOD/ERROR, CAP MODULE FAULT, AMP MODULE FAULT, OUT OF RANGE, OUT OF SP RANGE*, OVER TEMP (CAP), OVER TEMP (AMP), OVER OUTPUT, OVER DISPLAY, ILLEGAL LRV, ILLEGAL HRV, ILLEGAL SPAN, and ZERO ADJ OVER |  | ○             | ○ | ○ |
| B   | SENSOR TYPE  | Sensor type                              | –             | Menu name  |  | ○             | ○ | ○ |
| B10 | MODEL        | Model+span                               | –             | 16 uppercase alphanumerics   |  | ○             | ○ | ○ |
| B11 | STYLE NO.    | Style number                             | –             |  |  | ○             | ○ | ○ |
| B20 | LRL          | Lower range-limit                        | –             | –32000 to 32000  |  | ○             | ○ | ○ |
| B21 | URL          | Upper range-limit                        | –             | –32000 to 32000  |  | ○             | ○ | ○ |
| B30 | MIN SPAN     | Minimum span                             | –             | –32000 to 32000  |  | ○             | ○ | ○ |
| B40 | MAX STAT.P.  | Maximum atatic pressure                  | –             |  |  | ○             | – | ○ |
| B60 | SELF CHECK   | Self-diagnostic messages                 | –             | Same as A60  |  | ○             | ○ | ○ |
| C   | SETTING      | Setting data                             | –             | Menu name  |  | ○             | ○ | ○ |
| C10 | TAG. NO.     | Tag number                               | ○             | 16 alphanumerics   | As specified when ordered.                                       | ○             | ○ | ○ |
| C20 | PRESS UNIT   | Measurement range units                  | ○             | Selected from mmH <sub>2</sub> O, mmAq, mmWG, mmHg, Torr, Pa, hPa, kPa, MPa, mbar, bar, gf/cm <sup>2</sup> , kgf/cm <sup>2</sup> , inH <sub>2</sub> O, inHg, ftH <sub>2</sub> O, psi, or atm           | As specified when ordered.                                       | ○             | ○ | ○ |
| C21 | LOW RANGE    | Measurement range, lower range value     | ○             | –32000 to 32000 (but within measurement range)   | As specified when ordered.                                       | ○             | ○ | ○ |
| C22 | HIGH RANGE   | Measurement range, higher range value    | ○             | –32000 to 32000 (but within measurement range)   | As specified when ordered.                                       | ○             | ○ | ○ |
| C30 | AMP DAMPING  | Damping time constant                    | ○             | Selected from 0.2, 0.5, 1.0, 2.0, 4.0, 8.0, 16.0, 32.0, or 64.0 sec.   | 2 s  | ○             | ○ | ○ |
| C40 | OUTPUT MODE  | Output mode and integral indicator mode  | ○             | Selected from OUT:LIN; DSP:LIN, OUT:LIN; DSP:SQR, OUT:SQR; DSP:SQR   | As specified when ordered. If not specified, OUT: LIN; DSP: LIN. | ○             | – | – |
| C60 | SELF CHECK   | Self-diagnostic messages                 | –             | Same as A60  |  | ○             | ○ | ○ |
| D   | AUX SET 1    | Auxiliary setting data 1                 | –             | Menu name  |  | ○             | ○ | ○ |
| D10 | LOW CUT      | Low cut                                  | ○             | 0.0 to 20.0%   |  | ○             | ○ | ○ |
| D11 | LOW CUT MODE | Low cut mode                             | ○             | LINEAR/ZERO  |  | ○             | ○ | ○ |
| D20 | DISP SELECT  | Display selection                        | ○             | NORMAL %/USER SET, USER & %/INP PRES, PRES & %   |  | ○             | ○ | ○ |

\* In case of Model EJA120, static pressure cannot be measured. The display is always 0 MPa, but this is not a measured value.

T0805.EPS

8. BRAIN TERMINAL BT200 OPERATION

| No. | Item          | Description  | Rewritability | Remarks  | Default Value                                     | Applicability |   |   |
|-----|---------------|--|---------------|--|---|---------------|---|---|
|     |               |  |               |  |   | F             | P | L |
| D   | AUX SET 1     | Auxiliary setting data 1                             | –             | Menu name  |   | ○             | ○ | ○ |
| D21 | DISP UNIT     | Engineering unit for display                         | ○             | 8 uppercase alphanumerics  | As specified when ordered.                        | ○             | ○ | ○ |
| D22 | DISP LRV      | Engineering range, lower range value                 | ○             | –19999 to 19999  |   | ○             | ○ | ○ |
| D23 | DISP HRV      | Engineering range, higher range value                | ○             | –19999 to 19999  | As specified when ordered.                        | ○             | ○ | ○ |
| D30 | TEMP UNIT     | Temperature setting units                            | ○             | deg C/deg F  | deg C   | ○             | ○ | ○ |
| D31 | STAT. P. UNIT | Static pressure setting units                        | ○             | Selected from mmH <sub>2</sub> O, mmAq, mmWG, mmHg, Torr, Pa, hPa, kPa, MPa, mbar, bar, gf/cm <sup>2</sup> , kgf/cm <sup>2</sup> , inH <sub>2</sub> O, inHg, ftH <sub>2</sub> O, psi, or atm | As specified when ordered. If not specified, MPa. | ○             | – | ○ |
| D40 | REV OUTPUT    | Output reversal                                      | ○             | NORMAL/REVERSE   | If not specified, NORMAL.                         | ○             | ○ | ○ |
| D45 | H/L SWAP      | Impulse piping accessing direction                   | ○             | NORMAL/REVERSE**   | NORMAL  | ○             | – | – |
| D52 | BURN OUT      | CPU error  | –             | HIGH/LOW   | HIGH  | ○             | ○ | ○ |
| D53 | ERROR OUT     | Hardware error                                       | ○             | HOLD/HIGH/LOW  | HIGH  | ○             | ○ | ○ |
| D60 | SELF CHECK    | Self-diagnostic messages                             | –             | Same as A60  |   | ○             | ○ | ○ |
| E   | AUX SET 2     | Auxiliary setting data 2                             | –             | Menu name  |   | ○             | ○ | ○ |
| E30 | BI DIRE MODE  | Bidirectional mode                                   | ○             | OFF/ON   | OFF   | ○             | – | – |
| E60 | SELF CHECK    | Self-diagnostic messages                             | –             | Same as A60  |   | ○             | ○ | ○ |
| H   | AUTO SET      | Automatic setup                                      | –             | Menu name  |   | ○             | ○ | ○ |
| H10 | AUTO LRV      | Automatic measurement range lower range value setup  | ○             | –32000 to 32000  | Displays the same data as C21.                    | ○             | ○ | ○ |
| H11 | AUTO HRV      | Automatic measurement range higher range value setup | ○             | –32000 to 32000  | Displays the same data as C22.                    | ○             | ○ | ○ |
| H60 | SELF CHECK    | Self-diagnostic messages                             | –             | Same as A60  |   | ○             | ○ | ○ |
| J   | ADJUST        | Adjustment data                                      | –             | Menu name  |   | ○             | ○ | ○ |
| J10 | ZERO ADJ      | Automatic zero adjustment                            | ○             | –5 to 110.0%   |   | ○             | ○ | ○ |
| J11 | ZERO DEV.     | Manual zero adjustment                               | ○             |  |   | ○             | ○ | ○ |
| J20 | EXT. ZERO ADJ | External zero-adjustment screw permission            | ○             | ENABLE/INHIBIT   |   | ○             | ○ | ○ |
| J60 | SELF CHECK    | Self-diagnostic messages                             | –             | Same as A60  |   | ○             | ○ | ○ |
| K   | TEST          | Tests  | –             | Menu name  |   | ○             | ○ | ○ |
| K10 | OUTPUT in %   | Test output % setting                                | ○             | –5 to 110.0% Displays 'ACTIVE' while executing   |   | ○             | ○ | ○ |
| K60 | SELF CHECK    | Self-diagnostic messages                             | –             | Same as A60  |   | ○             | ○ | ○ |
| M   | MEMO          | Memo   | –             | Menu name  |   | ○             | ○ | ○ |
| M10 | MEMO 1        | Memo   | ○             | 8 uppercase alphanumerics  |   | ○             | ○ | ○ |
| M20 | MEMO 2        | Memo   | ○             | 8 uppercase alphanumerics  |   | ○             | ○ | ○ |
| M30 | MEMO 3        | Memo   | ○             | 8 uppercase alphanumerics  |   | ○             | ○ | ○ |
| M40 | MEMO 4        | Memo   | ○             | 8 uppercase alphanumerics  |   | ○             | ○ | ○ |
| M50 | MEMO 5        | Memo   | ○             | 8 uppercase alphanumerics  |   | ○             | ○ | ○ |
| M60 | SELF CHECK    | Self-diagnostic messages                             | –             | Same as A60  |   | ○             | ○ | ○ |
| P   | RECORD        | History of the errors                                | –             |  |   | ○             | ○ | ○ |
| P10 | ERROR REC 1   | Last error   | ○             | Display the error  |   | ○             | ○ | ○ |
| P11 | ERROR REC 2   | One time before                                      | ○             | Display the error  |   | ○             | ○ | ○ |
| P12 | ERROR REC 3   | Two time before                                      | ○             | Display the error  |   | ○             | ○ | ○ |
| P13 | ERROR REC 4   | Three time before                                    | ○             | Display the error  |   | ○             | ○ | ○ |
| P60 | SELF CHECK    | Self-diagnostic messages                             | –             | Same as A60  |   | ○             | ○ | ○ |

\*\* Not applicable for Model EJA115.

### 8.3.2 Parameter Usage and Selection

Before describing the procedure for setting parameters, we present the following table showing how the parameters are used and in what case.



#### IMPORTANT

If the transmitter is turned off within 30 seconds after parameters have been set, the set data will not be stored and the terminal returns to previous settings.

Table 8.3.1 Parameter Usage and Selection

| Setup Item  | Description  |
|---|--|
| <b>Tag No. setup</b><br>▶ P.8-7                                     | Sets the Tag No. (using 16 alphanumeric characters).<br>Note: Up to 8 alphanumerics (upper case letters) can be used in the BT100.   |
| <b>Calibration range setup</b><br>▶ P.8-7                           | Sets the calibration range for 4 to 20 mA DC. Sets three data items: range unit, input value at 4 mA DC (LRV), and input value at 20 mA DC (HRV).<br>Note: LRV and HRV can be specified with range value specifications up to 5 digits (excluding any decimal point) within the range of -32000 to 32000.  |
| <b>Damping time constant setup</b><br>▶ P.8-8                       | Adjusts the output response speed for 4 to 20 mA DC.<br>Can be set in 9 increments from 0.2 to 64 s.   |
| <b>Output and integral indicator display mode setup</b> ▶ P.8-9     | Sets modes for output signal and integral indicator to "Linear mode" (proportional to input differential pressure) or to "Square root mode" (proportional to flow).  |
| <b>Output signal low cut mode setup</b><br>▶ P.8-9                  | Used mainly to stabilize output near 0% if output signal is the square root mode. Two modes are available: forcing output to 0% for input below a specific value, or changing to proportional output for input below a specific value.   |
| <b>Integral indicator scale range and unit setup</b><br>▶ P.8-10    | Sets the following 5 types of integral indicator scale ranges and units:<br>% scale indicator, user set scale indicator, alternate indication of user set scale and % scale, input pressure display, alternate indication of input pressure and % scale<br>When using the user set scale, 4 types of data can be set:<br>user set scale setting, unit (BT200 only), display value at 4 mA DC (LRV), and display value at 20 mA DC (HRV).<br>Note: LRV and HRV can be specified with range value specifications up to 5 digits (excluding any decimal point) within the range of -19999 to 19999. |
| <b>Unit setup for displayed temperature</b><br>▶ P.8-11             | Sets a unit for temperatures displayed on the BT200.   |
| <b>Unit setup for displayed static pressure</b><br>▶ P.8-12         | Sets a unit for static pressure displayed on the BT200.  |
| <b>Operation mode (normal/reverse signal) setup</b><br>▶ P.8-12     | Reverses the direction for 4 to 20 mA DC output relative to input.<br>Reverse mode is used for applications in which safety requires that output be driven toward 20 mA if input is lost.  |
| <b>Output status display/setup when a CPU failure</b> ▶ P.8-12      | Displays the status of 4 to 20 mA DC output when a CPU failure. The parameter of the standard unit is fixed to the high limit value.   |
| <b>Output status setup when a hardware error occurs</b><br>▶ P.8-12 | Sets the status of the 4 to 20 mA DC output when an abnormal status is detected with the capsule or the amplifier as the result of self-diagnosis. One of the following statuses; last held, high limit, and low limit values, can be selected.  |
| <b>Range change (while applying actual inputs)</b><br>▶ P.8-13      | Range for 4 to 20 mA DC signal is set with actual input applied. Sets 20 mA DC output precisely with respect to user's reference instrument output. Note that DPharp is calibrated with high accuracy before shipment, so span should be set using the normal range setup.   |
| <b>Zero point adjustment</b><br>▶ P.8-13                            | Adjusts zero point. This can be done either using the external zero-adjustment screw on the transmitter or using the BT200.  |
| <b>Test output (fixed current output) setup</b> ▶ P.8-14            | Used for loop checks.<br>Output can be set freely from -5% to 110% in 1% steps.  |
| <b>User memo fields</b><br>▶ P.8-14                                 | Allows user to enter up to 5 items of any desired text in up to 8 uppercase alphanumeric characters per item.  |

T0807.EPS

### 8.3.3 Setting Parameters

Set or change the parameters as necessary. After completing these, do not fail to use the “DIAG” key to confirm that “GOOD” is displayed for the self-diagnostic result at **\_60: SELF CHECK**.

#### (1) Tag No. Setup (C10: TAG NO)

Use the procedure below to change the Tag No. Up to 16 alphanumeric characters can be entered.


• Example: Set a Tag No. to FIC-1a




Press the **ON/OFF** key to turn on the BT200.




Connect DPharp and BT200 using a communication cable and press the **ENTER** key.




Displays the name of connected DPharp model, TAG NO. and diagnostics information. Press the **F4** (OK) key after confirmation.




Press the **F2** (SET) key to display the SET menu panel.



Select C: SETTING and press the **ENTER** key.




Select C10: TAG NO. and press the **ENTER** key.



Set the new TAG NO. (FIC-1a).


|   |       |          |
|---|-------|----------|
| <b>SHIFT</b> <b>E</b> <b>9</b> <b>F</b>                       | F     | OKOGAWA  |
| <b>SHIFT</b> <b>I</b> <b>5</b> <b>J</b>                       | I     | FIKOGAWA |
| <b>SHIFT</b> <b>C</b> <b>8</b> <b>D</b>                       | C     | FICOGAWA |
| <b>W</b> <b>X</b>   | X     | FIC-GAWA |
| <b>M</b> <b>1</b> <b>N</b>                                    | 1     | FIC-1AWA |
| <b>F2</b> <b>SHIFT</b> <b>A</b> <b>7</b> <b>B</b>             | 7     | FIC-1aWA |
| <b>Y</b> <b>Z</b> <b>SPACE</b> <b>Y</b> <b>Z</b> <b>SPACE</b> | SPACE | FIC-1a   |

Set TAG NO. and press the **ENTER** key.




( When you have made an entry mistake, return the cursor **<** using the key, then reenter. )


F0810.EPS



This is the panel for confirming set data. The set data items flash. When all items have been confirmed, press the **ENTER** again. (To go back to the setting panel, press the **F3** (NO) key.



The DPharp TAG NO. was overwritten. Press the **F4** (OK) key to return to the parameter panel. Press the **F3** (NO) key to return to the setting panel.




F0811.EPS

#### (2) Calibration Range Setup


##### a. Setting Calibration Range Unit (C20: PRESS UNIT)

The unit is set at the factory before shipment if specified at the time of order. Follow the procedure below to change the unit.

• Example: Change the unit from mmH<sub>2</sub>O to kPa.



Use the **▲** or **▼** key to select “kPa.” Press the **ENTER** key twice to enter the setting.



Press the **F4** (OK) key.



F0812.EPS

**b. Setting Calibration Range Lower Range Value and Higher Range Value (C21: LOW RANGE, C22: HIGH RANGE)**

These range values are set as specified in the order before the instrument is shipped. Follow the procedure below to change the range.

- The measurement span is determined by the high and low range limit values. In this instrument, changing the low range value also automatically changes the high range value, keeping the span constant.

• Example 1: With present settings of 0 to 30 kPa, set the lower range value to 0.5 kPa.

```
SET
C21:LOW RANGE
  0 kPa
+ 0.5
DEL CLR ESC
```

Set **0.5**.  
Press the **ENTER** key twice to enter the setting.

```
SET
C21:LOW RANGE
  0.5 kPa
FEED NO OK
```

Press the **F4** (OK) key.

```
PARAM
C20:PRESS UNIT
  kPa
C21:LOW RANGE
  0.5 kPa
C22:HIGH RANGE
  30.5 kPa
DATA DIAG PRNT ESC
```

The higher range value is changed while the span remains constant.

( Span = Higher range value – Lower range value )

F0813.EPS

- Note, however, that changing the higher range value does not cause the lower range value to change. Thus, changing the higher range value also changes the span.
- Calibration range can be specified with range value specifications up to 5 digits (excluding any decimal point) for low or high range limits within the range of -32000 to 32000.

- Example 2: With present settings of 0 to 30 kPa, set the Higher range value to 10 kPa.

```
SET
C22:HIGH RANGE
  30 kPa
  10
DEL CLR ESC
```

Set **10**.  
Press the **ENTER** key twice to enter the setting.

```
SET
C22:HIGH RANGE
  10 kPa
FEED NO OK
```

Press the **F4** (OK) key.

```
PARAM
C20:PRESS UNIT
  kPa
C21:LOW RANGE
  0 kPa
C22:HIGH RANGE
  10 kPa
DATA DIAG PRNT ESC
```

The low range value is not changed, so the span changes.

F0814.EPS

**(3) Damping Time Constant Setup (C30: AMP DAMPING)**

When the instrument is shipped, the damping time constant is set at 2.0 seconds. Follow the procedure below to change the time constant.

- Example: Change from 2.0 sec to 4.0 sec.

```
SET
C30:AMP DAMPING
  2.0 sec
  2.0 sec
< 4.0 sec >
< 8.0 sec >
< 16.0 sec >
ESC
```

Use the **^** or **v** key to select **4.0 sec**.  
Press the **ENTER** key twice to enter the setting.

```
SET
C30:AMP DAMPING
  4.0 sec
FEED NO OK
```

Press the **F4** (OK) key.

```
0.2sec
0.5sec
1.0sec
2.0sec
4.0sec
8.0sec
16.0sec
32.0sec
64.0sec
```

F0815.EPS

Note: The damping time constant set here is the damping time constant for the amplifier assembly. The damping time constant for the entire transmitter is the sum of the values for the amplifier assembly and for the capsule assembly. For the capsule assembly damping time constant (fixed), see the "General Specifications" found at the end of this manual. (See Chapter 10.)

**(4) Output Mode and Integral Indicator Display Mode Setup (C40: OUTPUT MODE)**

The mode setting for the output signal and the integral indicator coordinate as shown in the table below.

| BT200 Display     | Output Mode | Integral Indicator Display Mode |
|-------------------|-------------|---------------------------------|
| OUT: LIN DSP: LIN | Linear      | Linear                          |
| OUT: LIN DSP: SQR | Linear      | Square root                     |
| OUT: SQR DSP: SQR | Square root | Square root                     |

T0808.EPS

This mode is set as specified in the order when the instrument is shipped. Follow the procedure below to change the mode.

If the instrument is equipped with an integral indicator and the display mode is “square root”, “√” is displayed on the integral indicator.

For details, see Chapter 3.

• Example: Set output mode to **Linear** and display mode to **Square root**.

```
SET
C40:OUTPUT MODE
OUT:LIN DSP:LIN
<OUT:LIN DSP:LIN >
<OUT:LIN DSP:SQR >
<OUT:SQR DSP:SQR >
```

Use the or key to select “OUT: LIN, DSP: SQR.”

Press the key twice to enter the setting.

```
SET
C40:OUTPUT MODE
OUT:LIN DSP:SQR
```


Press the (OK) key.

F0816.EPS

**(5) Output Signal Low Cut Mode Setup (D10: LOW CUT, D11: LOW CUT MODE)**

Low cut mode can be used to stabilize the output signal near the zero point. The low cut point can be set in a range from 0 to 20% of output. (Hysteresis of cut point: ±1%)

Either “LINEAR” or “ZERO” can be selected as the low cut mode.



F0817.EPS

- Example: Change the low cut setting range from 10% to 20%, and the low cut mode from **LINEAR** to **ZERO**.

```
SET
D10:LOW CUT
10.0 %
+ 20.0
```

Set “20.”

Press the key twice to enter the setting.

```
SET
D10:LOW CUT
20.0 %
```

Press the (OK) key.

Next, the [D11: LOW CUT MODE] setting panel is displayed.

```
SET
D11:LOW CUT MODE
LINEAR
< LINEAR >
< ZERO >
```

Use the or key to select “ZERO.”

Press the key twice to enter the setting.

```
SET
D11:LOW CUT MODE
ZERO
```

Press the (OK) key.

```
PARAM
D10:LOW CUT
20.0 %
D11:LOW CUT MODE
ZERO
D20:DISP SELECT
NORMAL %
```

F0818.EPS

**(6) Integral Indicator Scale Setup**

The following 5 displays are available for integral indicators.

| D20: DISP SELECT and Display | Description and Related parameters  |
|------------------------------|---|
| <p>NORMAL %</p>              | <p>Indicates -5 to 110% range depending on the Measurement range (C21, C22).</p> <p>A10: OUTPUT (%)<br/>45.6 %</p>  |
| <p>USER SET</p>              | <p>Indicates values depending on the Engineering range (D22, D23). (Note 1) Units set using Engineering unit (D21) are not indicated.</p> <p>A11: ENGR. OUTPUT<br/>20.0 M</p> |
| <p>USER &amp; %</p>          | <p>Indicates user set and % alternately in 3 second intervals.</p> <p>A10: OUTPUT (%)<br/>45.6 %<br/>A11: ENGR. OUTPUT<br/>20.0 M</p>   |
| <p>INP PRES</p>              | <p>Indicates input pressure. Indication limits -19999 to 19999.</p> <p>A40: INPUT<br/>456 kPa</p>   |
| <p>PRES &amp; %</p>          | <p>Indicates input pressure and % alternately in 3 second intervals.</p> <p>A10: OUTPUT (%)<br/>45.6 %<br/>A40: INPUT<br/>456 kPa</p>   |

(Note 1) Scale range can be specified with range limit specifications up to 5 digits (excluding any decimal point) for low or high range limits within the range of -19999 to 19999.

T0809.EPS

See (a.) through (c.) for each setting procedure.

- Example: Change the low cut setting range from 10% to 20%, and the low cut mode from **LINEAR** to **ZERO**.

```
SET
D10:LOW CUT
 10.0 %
+ 20.0
```

Set "20."

Press the **ENTER** key twice to enter the setting.

```
SET
D10:LOW CUT
 20.0 %
```

Press the **F4** (OK) key.

Next, the [D11: LOW CUT MODE] setting panel is displayed.

```
SET
C11:LOW CUT MODE
  LINEAR
< LINEAR >
< ZERO >
```

Use the **^** or **v** key to select "ZERO."

Press the **ENTER** key twice to enter the setting.

```
SET
D11:LOW CUT MODE
ZERO
```

Press the **F4** (OK) key.

```
PARAM
D10:LOW CUT
 20.0 %
D11:LOW CUT MODE
ZERO
D20:DISP SELECT
NORMAL %
DATA  DIAG  PRNT  ESC
```

F0818.EPS

**a. Display Selection (D20: DISP SELECT)**

Follow the instructions given to the below to change the range of integral indication scales.

When **USER SET** is selected, the user set values of integral indication and **A11: ENGR. OUTPUT** parameter are indicated.

- Example: Set the integral indicator scale to engineering units display.

```
SET
D20:DISP SELECT
NORMAL %
<NORMAL %>
<USER SET>
<USER %>
<INP PRES>
```

Use the **^** or **v** key to select "USER SET"

Press the **ENTER** key twice to enter the setting.

```
SET
D20:DISP SELECT
USER SET
```

Press the **F4** (OK) key.

( The "%" disappears from the integral indicator display. )

F0820.EPS

8-10

IM 1C22K1-01E

**b. Setting User-set Engineering Unit (D21: DISP UNIT)**

This parameter allows entry of the engineering units to be displayed on the BT200. When the instrument is shipped, this is set as specified in the order.

Follow the procedure below to change this setting.

Since these units are not displayed on the integral indicator, use the adhesive labels provided. This parameter need not be set for % display.

• Example: Set an engineering unit **M**.

```
SET
D21:DISP UNIT
M
CODE CAPS CLR ESC
```

Set "M."  
Press the **ENTER** key twice to enter the setting.

```
SET
D21:DISP UNIT
M
FEED NO OK
```

Press the **F4** (OK) key.

F0821.EPS

**c. Lower and Higher Range Value Setup in Engineering Unit (D22: DISP LRV, D23: DISP HRV)**

These parameter items are used to set the lower and higher range values for the engineering unit display.

When the instrument is shipped, these are set as specified in the order. Follow the procedure below to change these settings. Note that these parameters need not be set for % display.

• Example: Set lower range value (LRV) to **-50** and higher range value (HRV) to **50**.

```
SET
D22:DISP LRV
- 50
DEL CLR ESC
```

Setting LRV  
Set "-50."  
Press the **ENTER** key twice to enter the setting.

```
SET
D23:DISP HRV
+ 50
DEL CLR ESC
```

Setting HRV  
Set "50."  
Press the **ENTER** key twice to enter the setting.

```
SET
D23:DISP HRV
50
FEED NO OK
```

Press the **F4** (OK) key.

```
PARAM
D21:DISP UNT
M
D22:DISP LRV
- 50M
D23:DISP HRV
50M
DATA DIAG PRNT ESC
```

F0822.EPS

**(7) Unit Setup for Displayed Temperature (D30: TEMP UNIT)**

When the instrument is shipped, the temperature units are set to **degC**. Follow the procedure below to change this setting. Note that changing the unit here changes the unit for **A20: AMP TEMP** (amplifier temperature) and **A21: CAPSULE TEMP** (capsule temperature).

• Example: Change the unit for the temperature display.

```
SET
D30:TEMP UNIT
deg C
< deg C >
< deg F >
ESC
```

Use the **^** or **v** key to select "deg F"  
Press the **ENTER** key twice to enter the setting.

F0823.EPS

**(8) Unit Setup for Displayed Static Pressure (D31: STAT.P.UNIT)**

Follow the procedure below to change the static pressure units.  
Changing this parameter changes the unit for the A30: STATIC PRESS (static pressure) display.

• Example: Change the static pressure unit from **kgf/cm<sup>2</sup>** to **MPa**.

```

SET
C31:STAT.P.UNIT
 kgf/cm^2
 < MPa >
 < mbar >
 < bar >
 < gf/cm^2 >
          
```

Use the or key to select "MPa."

Press the **ENTER** key twice to enter the setting.

```

mmH2O
mmHg
mmHg
mmHg
Torr
kPa
MPa
mbar
bar
gf/cm2
kgf/cm2
inH2O
inHg
ftH2O
psi
atm
Pa
hPa
          
```

F0824.EPS

**(9) Operation Mode Setup (D40: REV OUTPUT)**

This parameter allows the direction of the 4 to 20 mA output to be reversed with respect to input. Follow the procedure below to make this change.

• Example: Change 4 to 20 mA output to 20 to 4 mA output.

```

SET
D40:REV OUTPUT
 NORMAL
 < NORMAL >
 < REVERSE >
          
```

Use the or key to select REVERSE.

Press the **ENTER** key twice to enter the setting.

F0825.EPS

**(10) Output Status Display/Setup when a CPU Failure (D52: BURN OUT)**

This parameter displays the status of 4 to 20 mA DC output if a CPU failure occurs. In case of a failure, communication is disabled.

Setting of HIGH or LOW is enabled. This is done with the pin (CN4) on the CPU assembly. See Chapter 3 for details.

Standard specifications

The parameter is set to HIGH. If a failure, the transmitter outputs the signal of 110% or higher. The parameter **D53: ERROR OUT** is set to HIGH from the factory.

Optional code/C1

The parameter is set to LOW. If a failure, output which is -5% or lower is generated. The parameter **D53: ERROR OUT** is set to LOW from the factory.

• Example: Standard specifications

```

D52: BURN OUT
    HIGH
          
```

pin (CN4) position: H

• Example: Optional code/C1

```

D52: BURN OUT
    LOW
          
```

pin (CN4) position: L

F0826.EPS

**(11) Output Status Setup when a Hardware Error Occurs (D53: ERROR OUT)**

This parameter allows the setting of the output status when a hardware error occurs. The following three selections are available.

- (a) HOLD; Outputs the last value held before the error occurred.
- (b) HIGH; Outputs an output of 110% when an error has occurred.
- (c) LOW; Outputs an output of -5% when an error has occurred.

Note: A hardware error means CAP MODULE FAULT of Er.01 or AMP MODULE FAULT of Er. 02 which are shown in 8.5.2 "Errors and Countermeasures.")

• Example: Set the output status to LOW when a hardware error occurs.

```

SET
D53:ERROR OUT
    HIGH
 < HIGH >
 < LOW >
 < HOLD >
          
```

Use the or key to select "LOW."

Press the **ENTER** key twice to enter the setting.

F0827.EPS

**(12) Range Change while Applying Actual Inputs (H10: AUTO LRV, H11: AUTO HRV)**

This feature allows the lower and higher range values to be set up automatically with the actual input applied. If the lower and higher range values are set, **C21: LOW RANGE** and **C22: HIGH RANGE** are changed at this same time.

Follow the procedure in the figure below. The measurement span is determined by the higher and lower range values. Changing the lower range value results in the higher range value changing automatically, keeping the span constant.

- Example 1: When changing the lower range value to 0.5 kPa for the present setting of 0 to 30 kPa, take the following action with input pressure of 0.5 kPa applied.

```
SET
H10:AUTO LRV
  0 kPa
+ 0
```

Press the **ENTER** key twice.

The lower range value is changed to 0.5 kPa.

```
SET
H10:AUTO LRV
0.5000 kPa
```

Press the **F4** (OK) key.

```
PARAM
H10:AUTO LRV
0.5000 kPa
H11:AUTO HRV
30.500 kPa
H60:SELF CHEC
GOOD
```

The higher range value is changed keeping the span constant. Parameters **C21** and **C22** are changed at the same time.

F0828.EPS

Note that changing the higher range value does not cause the lower range value to change but does change the span.

- Example 2: When the higher range value is to be changed to 10 kPa with the present setting of 0 to 30 kPa, take the following action with an input pressure of 10 kPa applied.

```
SET
H10:AUTO HRV
  30 kPa
+ 30
```

Press the **ENTER** key twice.

The higher range value is changed to 10 kPa.

```
SET
H11:AUTO HRV
10.000 kPa
```

Press the **F4** (OK) key.

```
PARAM
H10:AUTO LRV
0 kPa
H11:AUTO HRV
10.000 kPa
H60:SELF CHEC
GOOD
```

The lower range value is not changed, so the span changes. Parameter **C22** is changed at the same time.

F0829.EPS

**(13) Zero Point Adjustment (J10: ZERO ADJ, J11: ZERO DEV, J20: EXT ZERO ADJ)**

The DPharp supports several adjustment methods. Select the method best suited for the conditions of your application.

Note that output signal can be checked by displaying parameter **A10:OUTPUT (%)** on the BT200.

| Adjustment Method                        | Description  |
|--|--|
| Using the BT200                          | <b>Set the present input to 0%.</b><br>Adjust for 0% output at input level of 0%.  |
|  | <b>Adjust output to the reference value obtained using other means.</b><br>If the input level cannot easily be made 0% (because of tank level, etc.), adjust output to the reference value obtained using other means, such as a sight glass.                    |
| Using the external zero-adjustment screw | Adjust zero point using the zero-adjustment screw on the transmitter. This permits zero adjustment without using the BT200. Accurately adjust the output current to 4 mA DC or other target output value using an ammeter that accurately reads output currents. |

T0810.EPS

- (a) Follow the procedure below when setting the present output to 0% (4 mA).

```
A10:OUTPUT (%)
  0.5 %
```

Output is 0.5%.

```
SET
J10:ZERO ADJ
  0.0 %
+ 000.0
```

Press the **ENTER** key twice.

```
SET
J10:ZERO ADJ
  0.0 %
```

Zero adjustment is completed.  
Press the **F4** (OK) key.

```
A10:OUTPUT (%)
  0.0 %
```

Output is 0%.

F0830.EPS

- (b) Zero Point Adjustment Using the External Zero Adjustment Screw

- Enabling/inhibiting of zero point adjustment using the external zero-adjustment screw on the transmitter (J20: EXT ZERO ADJ)

Follow the procedure below to enable or inhibit zero point adjustment from the zero-adjustment screw on the transmitter.

This is set to "ENABLE" when the instrument is shipped.

• Example: Inhibiting zero adjustment by the external zero-adjustment screw

```
SET
J20:EXIT ZERO ADJ
  ENABLE
< ENABLE >
< INHIBIT >
```

Use the **▲** or **▼** key to select "INHIBIT."  
Press the **ENTER** key twice to enter the setting.

F0831.EPS

- Zero point adjustment using external zero-adjustment screw on the transmitter

Turn the zero-adjustment screw on the outside of the transmitter case using a slotted screwdriver. Turn the screw to the right to increase the zero point or to the left to decrease the zero output; the zero adjusts in increments of 0.01% of the range setting.

Note that the amount of adjustment to the zero point changes according to the speed at which the screw is turned. To make fine adjustments, turn the screw slowly; to make coarse adjustments, turn the screw quickly.

Note: When a zero point adjustment has been made, do not turn off the transmitter less than 30 seconds after adjustment.

### (14) Test Output Setup (K10: OUTPUT X%)

This feature can be used to output a fixed current from 3.2 mA (-5%) to 21.6 mA (110%) for loop checks.

• Example: Output 12 mA (50%) fixed current.

```
SET
K10:OUTPUT X %
  0.0 %
+ 050.0
```

Set "50.0%."  
Press the **ENTER** key twice to output a fixed current at 50%.

```
SET
K10:OUTPUT X %
  50.0 % ACTIVE
```

"Active" is displayed while this is being executed.  
Press the **F4** (OK) key to cancel the fixed current output.

F0832.EPS



### IMPORTANT

- Test output is held for approximately 10 minutes, and then released automatically after the time has elapsed. Even if the BT200 power supply is turned off or the communication cable is disconnected during test output, it is held for approximately 10 minutes.
- Press the **F4** (OK) key to release test output immediately.

### (15) User Memo Fields (M: MEMO)

This feature provides 5 user memo fields, each holding up to 8 alphanumeric characters. Up to 5 items such as inspection date, inspector, and other information can be saved in these fields.

• Example: Save an inspection date of January 30, 1995.

```
PARAM
M10:MEMO 1
M20:MEMO 2
M30:MEMO 3
DATA  DIAG  PRNT  ESC
```

Set "95.1.30" in the order of year, month, and day.  
Press the **ENTER** key twice to enter the setting.

```
SET
M10:MEMO 1
  95.1.30_
```

F0833.EPS

## 8.4 Displaying Data Using the BT200

### 8.4.1 Displaying Measured Data

The BT200 can be used to display measured data.

The measured data is updated automatically every 7 seconds. In addition, the display can be updated to the present data value at any time by pressing the **F1** (DATA) key. For parameters associated with the display of measured data, see Subsection 8.3.1, “Parameter Summary.”

• Example: Display output.

The screenshot shows a menu with options A: DISPLAY and B: SENSOR TYPE. Below the menu are buttons for HOME, SET, ADJ, and ESC. The next screen shows parameters: A10: OUTPUT (%), A11: ENGR. OUTPUT, and A20: AMP TEMP. Arrows point to the output values (XX.X, YY.Y, ZZ deg C) and the DATA key. A note says 'Display "A10: OUTPUT (%)"' and 'Data is updated automatically at 7-second intervals.' A third screen shows the same parameters with a 'communi' error message.

F0834.EPS

### 8.4.2 Display Transmitter Model and Specifications

The BT200 can be used to display the model and specifications of the transmitter.

• Example: View transmitter model name.

The screenshot shows the menu with A: DISPLAY selected. A note says 'Press ENTER'. The next screen shows parameters: B10: MODEL (EJA115-DM), B11: STYLE NO. (S1.01), and B20: LRL (-98.07 kPa). A note says 'For the associated parameters, see Subsection 8.3.1, Parameter Summary.'

F0835.EPS

## 8.5 Self-Diagnostics

### 8.5.1 Checking for Problems

#### (1) Identifying Problems with BT200

The following four areas can be checked.

- Whether connections are good.
- Whether BT200 was properly operated.
- Whether settings were properly entered.
- History of the errors.

See examples below.

• Example 1: Connection errors

The screenshot shows a 'communication error' message. A note says 'Press the ON/OFF key. When the panel shown on the left appears, press the ENTER key.' Another note says 'Since communications will be unsuccessful if there is a problem in the connection to the BT200, the display at the left will appear. Recheck the connection. Press the F4 (OK) key.'

• Example 2: Setting entry errors

The screenshot shows a 'SELF CHECK ERROR' message. A note says 'The initial data panel shows the result of current transmitter diagnostics.' Another note says 'Press the F2 (DIAG) key in the parameter panel to go to the diagnostics panel (C60: SELF CHECK).' A third note says 'An error message is displayed when an error occurs in the diagnostics panel.'

F0836.EPS

• Example 3: Checking the history of the errors

```
MENU
J:ADJUST
K:TEST
M:MEMO
P:RECORD
HOME SET ADJ ESC
```

Connect the BT200 to the transmitter, and call item "P."

```
PARAM
P10:ERROR REC 1
      ERROR
P11:ERROR REC 2
      ERROR
P12:ERROR REC 3
      GOOD
DATA DIAG PRNT ESC
```

- P10: "ERROR REC 1" displays the last error.
- P11: "ERROR REC 2" displays the error one time before the last error occurred.
- P12: "ERROR REC 3" displays the error two times before the last error occurred.
- P13: "ERROR REC 4" displays the error three times before the last error occurred.

The history of up to four errors can be stored. When the 5th error has occurred, it is stored in "P10". The error stored in "P13" will be deleted, and then, the error in "P12" will be copied to "P13". In this sequence, the history of the most previously occurred error will be removed from memory. "GOOD" will be displayed if there was no previous error.

```
SET
P10:ERROR REC 1
      ERROR
      < ERROR >
      < ILLEGAL LRV >
      < ILLEGAL HRV >
      ESC
```

Select P10: ERROR REC1 and press the **ENTER** key to display the error message.

<(a) SETUP PANEL>

For the details of the messages listed below, see Table 8.5.1 Error Message Summary.

|                  |                 |               |
|------------------|-----------------|---------------|
| CAP MODULE FAULT | OVER TEMP (CAP) | ILLEGAL LRV   |
| AMP MODULE FAULT | OVER TEMP (AMP) | ILLEGAL HRV   |
| OUT OF RANGE     | OVER OUTPUT     | ILLEGAL SPAN  |
| OUT OF SP RANGE  | OVER DISPLAY    | ZERO ADJ OVER |

Note 1: Press the **ENTER** key twice in the setting panel (panel 1) to clear all error message (P10 to P13) information.

Note 2: After two hours from when an error occurs, the error message of that error will be recorded. Therefore, if you switch off the transmitter within two hours from when the error occurs, there is no history of that error stored in the transmitter, and this function is meaningless.

F0837.EPS

(2) Checking with Integral Indicator



**NOTE**

If an error is detected in the self-diagnostic, an error number is displayed on the integral indicator. If there is more than one error, the error number changes at two-second intervals. See Table 8.5.1 regarding the error numbers.



F0838.EPS

Figure 8.5.1 Identifying Problems Using the Integral Indicator

## 8.5.2 Errors and Countermeasures

The table below shows a summary of error messages.

**Table 8.5.1 Error Message Summary**

| Integral Indicator Display | BT200 Display           | Cause   | Output Operation during Error                                   | Countermeasure  |
|----------------------------|-------------------------|---|---|---|
| None                       | GOOD                    |   |   |   |
| ----                       | <b>ERROR</b>            |   |   |   |
| Er. 01                     | <b>CAP MODULE FAULT</b> | Capsule problem.  | Outputs the signal (Hold, High, or Low) set with parameter D53. | Replace capsule.  |
| Er. 02                     | <b>AMP MODULE FAULT</b> | Amplifier problem.  | Outputs the signal (Hold, High, or Low) set with parameter D53. | Replace amplifier.  |
| Er. 03                     | <b>OUT OF RANGE</b>     | Input is outside measurement range limit of capsule.      | Outputs high range limit value or low range limit value.        | Check input.  |
| Er. 04                     | <b>OUT OF SP RANGE</b>  | Static pressure exceeds specified range.*1                | Displays present output.  | Check line pressure (static pressure).                                |
| Er. 05                     | <b>OVER TEMP (CAP)</b>  | Capsule temperature is outside range (–50 to 130°C).      | Displays present output.  | Use heat insulation or make lagging to keep temperature within range. |
| Er. 06                     | <b>OVER TEMP (AMP)</b>  | Amplifier temperature is outside range (–50 to 95°C).     | Displays present output.  | Use heat insulation or make lagging to keep temperature within range. |
| Er. 07                     | <b>OVER OUTPUT</b>      | Output is outside high or low range limit value.          | Outputs high or low range limit value.                          | Check input and range setting, and change them as needed.             |
| Er. 08                     | <b>OVER DISPLAY</b>     | Displayed value is outside high or low range limit value. | Displays high or low range limit value.                         | Check input and display conditions and modify them as needed.         |
| Er. 09                     | <b>ILLEGAL LRV</b>      | LRV is outside setting range.                             | Holds output immediately before error occurrence.               | Check LRV and modify as needed.                                       |
| Er. 10                     | <b>ILLEGAL HRV</b>      | HRV is outside setting range.                             | Holds output immediately before error occurrence.               | Check HRV and modify as needed.                                       |
| Er. 11                     | <b>ILLEGAL SPAN</b>     | SPAN is outside setting range.                            | Holds output immediately before error occurrence.               | Check SPAN and change as needed.                                      |
| Er. 12                     | <b>ZERO ADJ OVER</b>    | Zero adjustment is too large.                             | Displays present output.  | Readjust zero point.  |

\*1: For Model EJA120, static pressure cannot be measured. The display is always 0 MPa, but this is not a measured value.

T0811 .EPS

# 9. MAINTENANCE

---

## 9.1 Overview



### WARNING

---

Since the accumulated process fluid may be toxic or otherwise harmful, take appropriate care to avoid contact with the body, or inhalation of vapors during draining condensate or venting gas in transmitter pressure-detector section and even after dismantling the instrument from the process line for maintenance.

---

Maintenance of the transmitter is easy due to its modular construction. This chapter describes the procedures for calibration, adjustment, and the disassembly and reassembly procedures required for component replacement.

Since the transmitters are precision instruments, carefully and thoroughly read the following sections for proper handling during maintenance.



### IMPORTANT

---

- As a rule, maintenance of this transmitter should be implemented in a maintenance service shop where the necessary tools are provided.
  - The CPU assembly contains sensitive parts that may be damaged by static electricity. Exercise care so as not to directly touch the electronic parts or circuit patterns on the board, for example, by preventing static electrification by using grounded wrist straps when handling the assembly. Also take precautions such as placing a removed CPU assembly into a bag with an antistatic coating.
- 

## 9.2 Calibration Instruments Selection

Table 9.2.1 shows the instruments required for calibration. Select instruments that will enable the transmitter to be calibrated or adjusted to the required accuracy.

The calibration instruments should be handled carefully so as to maintain the specified accuracy.

## 9.3 Calibration

Use the procedure below to check instrument operation and accuracy during periodic maintenance or troubleshooting.

- 1) Connect the instruments as shown in Figure 9.3.1 and warm up the instruments for at least five minutes.



### IMPORTANT

---

- To adjust the transmitter for highest accuracy, make adjustments with the power supply voltage and load resistance including leadwire resistances set close to the conditions under which the transmitter is installed.
  - Dismount the manifold assembly (see Subsection 9.4.4) and apply reference pressure on the high pressure side. (The low pressure side should be open to atmosphere.)
- 

- 2) Apply reference pressures of 0%, 50%, and 100% of the measurement range to the transmitter. Calculate the errors (differences between digital voltmeter readings and reference pressures) as the pressure is increased from 0% to 100% and is decreased from 100% to 0%, and confirm that the errors are within the required accuracy.


Note: When the output mode is set to SQRT, apply reference pressures of 0, 6.25, 25, 56.25, and 100%, instead.

Table 9.2.1 Instruments Required for Calibration

| Name               | Yokogawa-recommended Instrument  | Remarks  |
|--------------------|--|--|
| Power supply       | Model SDBT or SDBS distributor   | 4 to 20 mA DC signal   |
| Load resistor      | Model 2792 standard resistor [250 Ω ±0.005%, 3 W]  |  |
|                    | Load adjustment resistor [100 Ω ±1%, 1 W]  |  |
| Voltmeter          | Model 2501 A digital multimeter<br>Accuracy (10V DC range): ±(0.002% of rdg + 1 dgt)   |  |
| Digital manometer  | Model MT110, MT120 precision digital manometer<br>1) For 10 kPa class<br>Accuracy: ±(0.015% of rdg + 0.015% of F.S.) ..... for 0 to 10 kPa<br>±(0.2% of rdg + 0.1% of F.S.) ..... for -10 to 0 kPa<br>2) For 130 kPa class<br>Accuracy: ±0.02% of rdg ..... for 25 to 130 kPa<br>±5digits ..... for 0 to 25 kPa<br>±(0.2% of rdg + 0.1% of F.S.) ..... for -80 to 0 kPa<br>3) For 700 kPa class<br>Accuracy: ±(0.02% of rdg + 3digits) ..... for 100 to 700 kPa<br>±5 digits ..... for 0 to 100 kPa<br>±(0.2% of rdg + 0.1% of F.S.) ..... for -80 to 0 kPa<br>4) For 3000 kPa class<br>Accuracy: ±(0.02% of rdg + 10 digits) ..... for 0 to 3000 kPa<br>±(0.2% of rdg + 0.1% of F.S.) ..... for -80 to 0 kPa<br>5) For 130 kPa abs class<br>Accuracy: ±(0.03% of rdg + 6 digits) ..... for 0 to 130 kPa abs | Select a manometer having a pressure range close to that of the transmitter. |
| Pressure generator | Model 2657 pneumatic pressure standard for 200 kPa {2 kgf/cm <sup>2</sup> }, 25 kPa {2500 mmH <sub>2</sub> O}<br>Accuracy: ±0.05% of F.S. or ±0.1% setting (whichever is greater)  | Requires air pressure supply.  |
|                    | Dead weight gauge tester 25 kPa {2500mmH <sub>2</sub> O}<br>Accuracy: ±0.03% of setting  | Select the one having a pressure range close to that of the transmitter.     |
| Pressure source    | Model 6919 pressure regulator (pressure pump)<br>Pressure range: 0 to 133 kPa {1000 mmHg}  | Prepare the vacuum pump for negative pressure ranges.                        |

T0901.EPS

Note: The above table contains the instruments capable of performing calibration to the 0.2% level. Since special maintenance and management procedures involving traceability of each instrument to higher-level standards are required for calibration to the 0.1% level, there are difficulties in calibration to this level in the field. For calibration to the 0.1% level, contact Yokogawa representatives from which the instrument was purchased or the nearest Yokogawa office.



F0901.EPS

Figure 9.3.1 Instrument Connections

## 9.4 Disassembly and Reassembly

This section describes procedures for disassembly and reassembly for maintenance and component replacement.

Always turn OFF power and shut off and release pressures before disassembly. Use proper tools for all operations. Table 9.4.1 shows the tools required.

**Table 9.4.1 Tools for Disassembly and Reassembly**

| Tool                 | Quantity | Remarks  |
|----------------------|----------|--|
| Phillips screwdriver | 1        | JIS B4633, No. 2   |
| Slotted screwdriver  | 1        |  |
| Allen wrenches       | 2        | JIS B4648<br>One each, nominal 3 and 5 mm Allen wrenches |
| Wrench               | 1        | Width across flats, 17 mm                                |
| Torque wrench        | 1        |  |
| Adjustable wrench    | 1        |  |
| Socket wrench        | 1        | Width across flats, 16 mm                                |
| Socket driver        | 1        | Width across flats, 5.5 mm                               |
| Tweezers             | 1        |  |

T0902.EPS




### CAUTION

#### Precautions for CENELEC, SAA, and JIS Flameproof Type Transmitters

- Flameproof type transmitters must be, as a rule, removed to a non-hazardous area for maintenance and be disassembled and reassembled to the original state. For details, see "Installation and Operating Precautions for JIS Flameproof Equipment" later in this manual.
- On the flameproof type transmitters the two covers are locked, each by an Allen head bolt (shrouding bolt). When a shrouding bolt is driven clockwise by an Allen wrench, it is going in and cover lock is released, and then the cover can be opened.

When a cover is closed it should be locked by a shrouding bolt without fail. Tighten the shrouding bolt to a torque of 0.7 N·m.



F0902.EPS

**Figure 9.4 Shrouding Bolts**

### 9.4.1 Replacing the Integral Indicator



### CAUTION

#### Cautions for JIS Flameproof Type Transmitters

Users are prohibited by law from modifying the construction of a flameproof type transmitter. This would invalidate the agency approval and the transmitter's use in such rated area.

Thus the user is prohibited from using a flameproof type transmitter with its integral indicator removed, or from adding an integral indicator to a transmitter. If such modification is absolutely required, contact Yokogawa.

This subsection describes the procedure for replacing an integral indicator. (See Figure 9.4.1)


#### ■ Removing the Integral Indicator

- 1) Remove the cover.
- 2) Supporting the integral indicator by hand, loosen its two mounting screws.
- 3) Dismount the LCD board assembly from the CPU assembly.

When doing this, carefully pull the LCD board assembly straight forward so as not to damage the connector pins between it and the CPU assembly.

#### ■ Attaching the Integral Indicator

- 1) Align both the LCD board assembly and CPU assembly connectors and engage them.
- 2) Insert and tighten the two mounting screws.
- 3) Replace the cover.



F0903.EPS

**Figure 9.4.1 Removing and Attaching LCD Board Assembly and CPU Assembly**

### 9.4.2 Replacing the CPU Board Assembly

This subsection describes the procedure for replacing the CPU assembly. (See Figure 9.4.1)

#### ■ Removing the CPU Assembly

- 1) Remove the cover. If an integral indicator is mounted, refer to Subsection 9.4.1 and remove the indicator.
- 2) Turn the zero-adjustment screw to the position (where the screw head slot is horizontal) as shown in Figure 9.4.1.
- 3) Disconnect the output terminal cable (cable with brown connector at the end). When doing this, lightly press the side of the CPU assembly connector and pull the cable connector to disengage.
- 4) Use a socket driver (width across flats, 5.5mm) to loosen the two bosses.
- 5) Carefully pull the CPU assembly straight forward to remove it.
- 6) Disconnect the flat cable (cable with black connector at the end) that connects the CPU assembly and the capsule.



#### NOTE

Be careful not to apply excessive force to the CPU assembly when removing it.

#### ■ Mounting the CPU Assembly

- 1) Connect the flat cable (with black connector) between the CPU assembly and the capsule.
- 2) Connect the output terminal cable (with brown connector).



#### NOTE

Make certain that the cables are free of pinching between the case and the CPU assembly edge.

- 3) Align and engage the zero-adjustment screw pin with the groove on the bracket on the CPU assembly. Then insert the CPU board assembly straight onto the post in the amplifier case.
- 4) Tighten the two bosses. If the transmitter is equipped with an integral indicator, refer to Subsection 9.4.1 to mount the indicator.



#### NOTE

Confirm that the zero-adjustment screw pin is placed properly in the groove on the bracket prior to tightening the two bosses. If it is not, the zero-adjustment mechanism will be damaged.

- 5) Replace the cover.

### 9.4.3 Replacing the Process Connector Gaskets

This subsection describes process connector gasket replacement. (See Figure 9.4.2.)

- (a) Loosen the two bolts, and remove the process connectors.
- (b) Replace the process connector gaskets.
- (c) Remount the process connectors. Tighten the bolts securely and uniformly, and verify that there are no pressure leaks.




Figure 9.4.2 Removing and Mounting the Process Connector

### 9.4.4 Cleaning Manifold Assembly and Replacing Orifice

This subsection describes the procedures for cleaning the manifold assembly and replacing the orifice to change flow rate. (See Figure 9.4.3.)

#### ■ Removing the Manifold Assembly

- 1) Remove the process connector as shown in Subsection 9.4.3.
- 2) Remove the four bolts that connect the cover flange with the manifold.
- 3) Remove the spacer, orifice, and orifice gasket from inside the manifold.
- 4) Clean the manifold, spacer, and orifice, or replace them as necessary.

**IMPORTANT**

Exercise care as follows when cleaning the manifold assembly.

- Handle the manifold assembly with care, and be careful not to damage the inner part of the manifold, spacer, and orifice. Be especially careful not to damage or distort the orifice edge (orifice bore).
- Do not use a chlorinated or acidic solution for cleaning.
- Rinse thoroughly with clean water after cleaning.

**Reassembling the Manifold Assembly**

- 1) Reassemble the orifice gasket, orifice, and spacer into the manifold in that order.  
When reassembling, refer to Figure 9.4.3 to ensure that they are placed in the correct direction.  
Replace the orifice gasket with a new gasket.
- 2) Mount the process connector as shown in Subsection 9.4.3.
- 3) Mount the manifold on the cover flange with the four bolts. Tighten the four bolts uniformly to a torque of 39 to 49 N·m.  
Replace the manifold gaskets with new gaskets.
- 4) After completing reassembly, a leak test must be performed to verify that there are no pressure leaks.

**NOTE**

Exercise care as follows when reassembling the manifold assembly. (See Figure 9.4.3.)

- Be careful not to reassemble the orifice in the wrong direction. Note that the spacer is configured so that it cannot be placed in the reverse direction.
- When mounting the manifold on the cover flange, confirm the indication “flow direction” shown on the manifold surface and the high and low pressure sides of the pressure-detector section.

Mount the manifold so that the upstream side of process fluid flow is located at the high pressure side of the pressure-detection section.




Figure 9.4.3 Manifold Assembly

**9.4.5 Cleaning and Replacing the Capsule Assembly**

This subsection describes the procedures for cleaning and replacing the capsule assembly. (See Figure 9.4.4.)

**CAUTION****Cautions for JIS Flameproof Type Transmitters**

Users are prohibited by law from modifying the construction of a flameproof type transmitter. If you wish to replace the capsule assembly with one of a different measurement range, contact Yokogawa.

The user is permitted, however, to replace a capsule assembly with another of the same measurement range. When doing so, be sure to observe the following.

- The replacement capsule assembly must have the same part number as the one being replaced.
- The section connecting the transmitter and capsule assembly is a critical element in preservation of flameproof performance, and must be checked to verify that it is free of dents, scratches, and other defects.
- After completing maintenance, be sure to securely tighten the Allen screws that fasten the transmitter section and pressure-detector section together.

## ■ Removing the Capsule Assembly



### IMPORTANT

Exercise care as follows when cleaning the capsule assembly.

- Handle the capsule assembly with care, and be especially careful not to damage or distort the diaphragms that contact the process fluid.
- Do not use a chlorinated or acidic solution for cleaning.
- Rinse thoroughly with clean water after cleaning.




Figure 9.4.4 Removing and Mounting the Pressure-detector Section

- 1) Remove the CPU assembly as shown in Subsection 9.4.2.
- 2) Remove the two Allen screws that connect the transmitter section and pressure-detector section.
- 3) Separate the transmitter section and pressure-detector section.
- 4) Remove the nuts from the four flange bolts.
- 5) Hold the capsule assembly by hand and remove the cover flange.
- 6) Remove the capsule assembly.
- 7) Clean the capsule assembly or replace with a new one.

## ■ Reassembling the Capsule Assembly

- 1) Insert the capsule assembly between the flange bolts, paying close attention to the relative positions of the H (high pressure side) and L (low pressure side) marks on the capsule assembly. Replace the two capsule gaskets with new gaskets.
- 2) Install the cover flange on the high pressure side, and use a torque wrench to tighten the four nuts uniformly to a torque of 39 N·m.
- 3) After the pressure-detector section has been reassembled, a leak test must be performed to verify that there are no pressure leaks.
- 4) Reattach the transmitter section to the pressure-detector section.
- 5) Tighten the two Allen screws. (Tighten the screws to a torque of 5 N·m)
- 6) Install the CPU assembly according to Subsection 9.4.2.
- 7) After completing reassembly, adjust the zero point and recheck the parameters.

## 9.5 Troubleshooting

If any abnormality appears in the measured values, use the troubleshooting flow chart below to isolate and remedy the problem. Since some problems have complex causes, these flow charts may not identify all. If you have difficulty isolating or correcting a problem, contact Yokogawa service personnel.

### 9.5.1 Basic Troubleshooting

First determine whether the process variable is actually abnormal or a problem exists in the measurement system.

If the problem is in the measurement system, isolate the problem and decide what corrective action to take.

This transmitter is equipped with a self-diagnostic function which will be useful in troubleshooting; see Section 8.5 for information on using this function.







Figure 9.5.1 Basic Flow and Self-Diagnostics

### 9.5.2 Troubleshooting Flow Charts





F0909.EPS



F0910.EPS

# 10. GENERAL SPECIFICATIONS

## 10.1 Standard Specifications

Refer to GS 1C22T2-E for Fieldbus communication type marked with “◇”.

### ● Performance Specifications

See General Specifications sheet, GS 1C22K1-E.

### ● Functional Specifications

#### Span & Range Limits

| Differential Pressure Span | kPa       | inH <sub>2</sub> O (/D1) | mbar (/D3)  | mmH <sub>2</sub> O (/D4)      |
|----------------------------|-----------|--------------------------|-------------|-------------------------------|
| L Capsule                  | 1 to 10   | 4 to 40                  | 10 to 100   | 100 to 1000                   |
| M Capsule                  | 2 to 100  | 8 to 400                 | 20 to 1000  | 200 to 10000                  |
| H Capsule                  | 20 to 210 | 80 to 830                | 200 to 2100 | 0.05 to 5 kgf/cm <sup>2</sup> |

| Measurement Range | Water Equivalent Flow l/min | Air Equivalent Flow NI/min |
|-------------------|-----------------------------|----------------------------|
| L Capsule         | 0.016 to 7.2                | 0.44 to 198                |
| M Capsule         | 0.022 to 23.0               | 0.63 to 635                |
| H Capsule         | 0.07 to 33.0                | 2.0 to 910                 |

T1001.EPS

#### Zero Adjustment Limits:

Zero can be fully elevated or suppressed, within the Lower and Upper Range Limits of the capsule.

#### External Zero Adjustment “◇”:

External zero is continuously adjustable with 0.01% incremental resolution of span. Span may be adjusted locally using the digital indicator with range switch.

#### Output “◇”:

Two wire 4 to 20 mA DC output with digital communications, linear or square root programmable. BRAIN or HART FSK protocol are superimposed on the 4 to 20 mA signal.

#### Failure Alarm:

Output status at CPU failure and hardware error;  
Up-scale: 110%, 21.6 mA DC or more (standard)  
Down-scale: -5%, 3.2 mA DC  
Note: Applicable for Output signal code D and E

#### Damping Time Constant (1st order):

The sum of the amplifier and capsule damping time constant must be used for the overall time constant. Amp damping time constant is adjustable from 0.2 to 64 seconds.

| Capsule (Silicone Oil)      | L   | M   | H   |
|-----------------------------|-----|-----|-----|
| Time Constant (approx. sec) | 0.8 | 0.6 | 0.3 |

T1002.EPS

#### Ambient Temperature Limits:

- \* Safety approval codes may affect limits.  
-40 to 85°C (-40 to 185°F)  
-30 to 80°C (-22 to 176°F) with LCD Display

#### Process Temperature Limits:

- \* Safety approval codes may affect limits.  
-40 to 120°C (-40 to 248°F)

#### Working Pressure Limits (Silicone Oil)

2.7 kPa abs (20 mmHg abs) to maximum working pressure. See 'Model and Suffix Codes.'

### ● Installation

#### Supply & Load Requirements “◇”:

- \* Safety approvals can affect electrical requirements. See Section 6.6, 'Power Supply Voltage and Load Resistance.'

#### EMC Conformity Standards: CE , N200

For EMI (Emission): EN55011, AS/NZS 2064 1/2  
For EMS (Immunity): EN50082-2

#### Communication Requirements “◇”:

##### BRAIN

##### Communication Distance;

Up to 2 km (1.25 miles) when using CEV polyethylene-insulated PVC-sheathed cables. Communication distance varies depending on type of cable used.

##### Load Capacitance;

0.22 µF or less (see note)

##### Load Inductance;

3.3 mH or less (see note)

##### Input Impedance of communicating device;

10 kΩ or more at 2.4 kHz.

Note: For general-use and Flameproof type.

For Intrinsically safe type, please refer to 'Optional Specifications.'

##### HART

##### Communication Distance;

Up to 1.5 km (1 mile) when using multiple twisted pair cables. Communication distance varies depending on type of cable used.

Use the following formula to determine cable length for specific applications:

$$L = \frac{65 \times 10^6}{(R \times C)} - \frac{(C_f + 10,000)}{C}$$

Where:

L = length in meters or feet

R = resistance in Ω (including barrier resistance)

C = cable capacitance in pF/m or pF/ft

C<sub>f</sub> = maximum shunt capacitance of receiving devices in pF/m or pF/ft

● Physical Specifications

**Wetted Parts Materials:**

**Diaphragm, Cover flange, Process connector, Manifold, Orifice, and Drain/Vent Plug;**  
See 'Model and Suffix Codes'

**Capsule Gasket;**  
Teflon-coated SUS316L

**Process Connector Gasket;**  
PTFE Teflon

**Non-wetted Parts Materials:**

**Bolting;**  
SCM435 or SUS630

**Housing;**  
Low copper cast-aluminum alloy with polyurethane paint (Munsell 0.6GY3.1/2.0)

**Enclosure Classification;**  
JIS C0920 immersion proof (equivalent to NEMA 4X and IEC IP67)

**Cover O-rings;**  
Buna-N

**Data plate and tag;**  
SUS304

**Fill Fluid;**  
Silicone or Fluorinated oil (optional)

**Weight:**  
5.6 kg (12.3 lb) without mounting bracket

**Connections:**  
Refer to the 'Model and Suffix Codes' to specify the process and electrical connection type.




Figure 1. Working Pressure and Process Temperature

F1001.EPS

<Settings When Shipped “◇”>

|                       |  |                                      |   |
|-----------------------|--|--------------------------------------|---|
| Tag Number            | As specified in order *1                     | Calibration Range Lower Range Value  | As specified in order   |
| Output Mode           | 'Linear' unless otherwise specified in order | Calibration Range Higher Range Value | As specified in order   |
| Display Mode          | 'Square root'                                | Calibration Range Units              | Selected from mmH <sub>2</sub> O, mmAq, mmWG, mmHg, Pa, hPa, kPa, MPa, mbar, bar, gf/cm <sup>2</sup> , kgf/cm <sup>2</sup> , inH <sub>2</sub> O, inHg, ftH <sub>2</sub> O, or psi. (Only one unit can be specified) |
| Operation Mode        | 'Normal' unless otherwise specified in order |                                      |   |
| Damping Time Constant | '2 sec.'                                     |                                      |   |

T1003.EPS

Note 1: If Tag No. is no more than 16 alphanumeric characters (including - and .), it will be written into the tag plate and amplifier memory settings.

## 10.2 Model and Suffix Codes

### ● Model EJA115

[Style: S2]

| Model                         | Suffix Codes   | Description  |
|-------------------------------|--|--|
| <b>EJA115</b>                 | .....  | Low Flow transmitter   |
| Output Signal                 | -D .....<br>-E .....<br>-F .....   | 4 to 20 mA DC with digital communication (BRAIN protocol)<br>4 to 20 mA DC with digital communication (HART protocol) (Note 1)<br>Digital communication (FOUNDATION Fieldbus protocol) (Note 4)  |
| Measurement span<br>(capsule) | L .....<br>M .....<br>H .....  | 1 to 10 kPa {100 to 1000 mmH <sub>2</sub> O}<br>2 to 100 kPa {200 to 10000 mmH <sub>2</sub> O}<br>20 to 210 kPa {2000 to 21000 mmH <sub>2</sub> O}   |
| Wetted parts material         | S .....  | [Body] <sup>(Note 3)</sup> [Capsule] [Orifice]<br>JIS SCS14A JIS SUS316L <sup>(Note 2)</sup> JIS SUS316  |
| Process flange rating         | 2 .....<br>4 .....   | Rc1/2 female<br>1/2 NPT female   |
| —                             | 00 .....   | Always 00  |
| Bolts and nuts material       | A .....<br>B .....   | [Maximum working pressure]<br>(L capsule) (M, H capsule)<br>JIS SCM435 3.5 MPa {35 kgf/cm <sup>2</sup> } 14 MPa {140 kgf/cm <sup>2</sup> }<br>JIS SUS630 3.5 MPa {35 kgf/cm <sup>2</sup> } 14 MPa {140 kgf/cm <sup>2</sup> }   |
| Installation                  | -2 .....<br>-3 .....<br>-6 .....<br>-7 .....<br>-8 .....<br>-9 .....                 | Vertical impulse piping type, right side high pressure, manifold upside<br>Vertical impulse piping type, right side high pressure, manifold downside<br>Vertical impulse piping type, left side high pressure, manifold upside<br>Vertical impulse piping type, left side high pressure, manifold downside<br>Horizontal impulse piping type, right side high pressure<br>Horizontal impulse piping type, left side high pressure  |
| Electrical connection         | 0 .....<br>2 .....<br>3 .....<br>4 .....<br>5 .....<br>7 .....<br>8 .....<br>9 ..... | G1/2 female, one electrical connection<br>1/2 NPT female, two electrical connections without blind plug<br>Pg 13.5 female, two electrical connections without blind plug<br>M20 female, two electrical connections without blind plug<br>G1/2 female, two electrical connections and a blind plug<br>1/2 NPT female, two electrical connections and a blind plug<br>Pg 13.5 female, two electrical connections and a blind plug<br>M20 female, two electrical connections and a blind plug |
| Integral indicator            | D .....<br>E .....<br>N .....  | Digital indicator<br>Digital indicator with the range setting switch<br>(None)   |
| Mounting bracket              | A .....<br>B .....<br>C .....<br>D .....<br>N .....                                  | JIS SECC 2-inch pipe mounting (flat type)<br>JIS SUS304 2-inch pipe mounting (flat type)<br>JIS SECC 2-inch pipe mounting (L type)<br>JIS SUS304 2-inch pipe mounting (L type)<br>(None)   |
| Optional codes                |  | <input type="checkbox"/> Optional specification  |

T1004.EPS

Example: EJA115-DMS400A-92NN/

Note 1: Refer to GS 1C22T1-E for HART Protocol version.

Note 2: Indicates other wetted parts materials. Diaphragm material is Hastelloy C-276.

Note 3: Indicates material of cover flanges and process connectors. Manifold and vent plugs material are JIS SUS316.

Note 4: Refer to GS 1C22T2-E for Fieldbus communication.

### 10.3 Optional Specifications

| Item                                     | Description   | Code       |
|--|---|------------|
| Factory Mutual (FM)                      | FM Explosionproof Approval<br>Explosionproof for Class I, Division 1, Groups B, C and D<br>Dust-ignitionproof for Class II/III, Division 1, Groups E, F and G<br>Hazardous (classified) locations, indoors and outdoors ( NEMA 4X )<br>Temperature class: T6<br>Amb. Temp.: -40 to 60 °C (-40 to 140 °F)<br>Electrical connection: 1/2 NPT female   | <b>FF1</b> |
|  | FM Intrinsically safe Approval<br>Intrinsically Safe for Class I, Division 1, Groups A, B, C & D, Class II, Division 1, Groups E, F & G and Class III, Division 1 Hazardous Locations.<br>Nonincendive for Class I, Division 2, Groups A, B, C & D, Class II, Division. 2, Groups E, F & G, and Class III, Division 1 Hazardous Locations.<br>Enclosure: "NEMA 4X", Temp. Class: T4, Amb. Temp.: -40 to 60 °C (-40 to 140 °F)<br>Intrinsically Safe Apparatus Parameters<br>[Groups A, B, C, D, E, F and G]<br>V <sub>max</sub> =30 V, I <sub>max</sub> =165 mA, P <sub>max</sub> =0.9 W, C <sub>i</sub> =22.5 nF, L <sub>i</sub> =730 μH<br>[Groups C, D, E, F and G]<br>V <sub>max</sub> =30 V, I <sub>max</sub> =225 mA, P <sub>max</sub> =0.9 W, C <sub>i</sub> =22.5 nF, L <sub>i</sub> =730 μH<br>Electrical connection: 1/2 NPT female | <b>FS1</b> |
|  | Combined FF1 and FS1<br>Electrical connection: 1/2 NPT female   | <b>FU1</b> |
| CENELEC (KEMA)                           | CENELEC (KEMA) Flameproof Approval<br>EExd IIC T4, T5, T6, Amb. Temp.: -40 to 80 °C (-40 to 176 °F)<br>Max. process Temp.: T4; 120 °C (248 °F), T5; 100 °C (212 °F), T6; 85 °C (185 °F)<br>Electrical connection: 1/2 NPT female, Pg 13.5 female and M20 female   | <b>KF1</b> |
|  | CENELEC (KEMA) Intrinsically safe Approval<br>EEx ia IIC T4, Amb. Temp.: -40 to 60 °C (-40 to 140 °F)<br>U <sub>i</sub> =30 V, I <sub>i</sub> =165 mA, P <sub>i</sub> =0.9 W, C <sub>i</sub> =22.5 nF, L <sub>i</sub> =730 μH<br>Electrical connection: 1/2 NPT female, Pg 13.5 female and M20 female   | <b>KS1</b> |
|  | Combined KF1, KS1 and Type N Approval<br>KEMA Type N Approval<br>Ex nA IIC T4, Amb. Temp.: -40 to 60 °C (-40 to 140 °F)<br>U=30 V, I=165 mA<br>Electrical connection: 1/2 NPT female, Pg 13.5 female and M20 female   | <b>KU1</b> |
| Canadian Standards Association (CSA)     | CSA Explosionproof Approval<br>Explosionproof for Class I, Division 1, Groups B, C and D<br>Dustignitionproof for Class II/III, Division 1, Groups E, F and G<br>Division2 'SEALS NOT REQUIRED', Temp. Class : T4, T5, T6 Encl Type 4x<br>Max. Process Temp.: T4; 120 °C (248 °F), T5; 100 °C (212 °F), T6; 85 °C (185 °F)<br>Amb. Temp.: -40 to 80 °C (-40 to 176 °F)<br>Electrical connection: 1/2 NPT female   | <b>CF1</b> |
|  | CSA Intrinsically safe Approval<br>Class I, Groups A, B, C and D Class II and III, Groups E, F and G<br>Encl Type 4x, Temp. Class: T4, Amb. Temp.: -40 to 60 °C (-40 to 140 °F)<br>V <sub>max</sub> =30 V, I <sub>max</sub> =165 mA, P <sub>max</sub> =0.9 W, C <sub>i</sub> =22.5 nF, L <sub>i</sub> =730 μH<br>Electrical connection: 1/2 NPT female  | <b>CS1</b> |
|  | Combined CF1 and CS1<br>Electrical connection: 1/2 NPT female   | <b>CU1</b> |
| Standards Association of Australia (SAA) | SAA Flameproof, Intrinsically safe and Non-sparking Approval<br>Ex d IIC T4/T5/T6, IP67 class I, Zone 1, Amb. Temp. : -40 to 80 °C (-40 to 176 °F)<br>Max. Process Temp.: T4; 120 °C (248 °F), T5; 100 °C (212 °F), T6; 85 °C (185 °F)<br>Ex ia IIC T4, IP67 class I, Zone 0<br>Ex n IIC T4, IP67 class I, Zone 2<br>U <sub>i</sub> =30 V DC, I <sub>i</sub> =165 mA DC, W <sub>i</sub> =0.9 W, Amb. Temp.: -40 to 60 °C (-40 to 140 °F)<br>Electrical connection: 1/2 NPT female, Pg 13.5 female and M20 female  | <b>SU1</b> |
| Japanese Industrial Standards (JIS)      | JIS Flameproof Approval, Ex do IIC T4X<br>Amb. Temp. -20 to 60 °C, Process Temp. -20 to 120 °C  | <b>JF3</b> |
|  | JIS Intrinsically safe Approval, Ex ia IIC T4<br>Amb. Temp. -20 to 60 °C, Process Temp. -20 to 120 °C   | <b>JS1</b> |
| Attached flameproof packing adapter      | Electrical connection: G1/2 female  | 1 pc.      |
|  | Applicable cable O.D.: 8 to 12 mm   | 2 pcs.     |

T1005.EPS

## 10. GENERAL SPECIFICATIONS

| Item  |                | Description   | Code  |
|---|----------------|---|---|
| Painting  | Color change   | Amplifier cover only  | P□  |
|   | Coating change | Epoxy resin-baked coating   | X1  |
| Lightning protector                                   |                | Transmitter power supply voltag: 10.5 to 32 V DC (10.5 to 30 V DC for intrinsically safe type, 9 to 32 V DC for Fieldbus communication type.)<br>Allowable current: Max. 6000 A (1×40 μs), Repeating 1000 A (1×40 μs) 100 times | A   |
| Oil-prohibited use                                    |                | Degrease cleansing treatment  | K1  |
|   |                | Degrease cleansing treatment and with fluorinated oilfilled capsule.<br>Operating temperature -20 to 80 °C  | K2  |
| Oil-prohibited use with dehydrating treatment         |                | Degrease cleansing treatment and dehydrating treatment  | K5  |
|   |                | Degrease cleansing treatment and dehydrating treatment with fluorinated oilfilled capsule.<br>Operating temperature -20 to 80 °C  | K6  |
| Calibration units                                     |                | P calibration ( psi unit )  | ( See Table for Span and Range Limits.)   |
|   |                | bar calibration ( bar unit )  |   |
|   |                | M calibration (kgf/cm <sup>2</sup> unit )   |   |
| Sealing treatment to SUS630 nuts                      |                | Sealant ( liquid silicone rubber ) is coated on surfaces of SUS630 nuts used for cover flange mounting.   | Y   |
| Long vent <sup>(Note 1)</sup>                         |                | Total vent plug Length: 112 mm (standard, 32 mm)  | U   |
| Fast response   |                | Update time: 0.125 sec or less, see GS for the response time  | F1  |
| Failure alarm down-scale <sup>(Note 2)</sup>          |                | Output status at CPU failure and hardware error: -5%, 3.2 mA DC or less.<br>When combining with Optional code F1, output signal is -2.5%, 3.6 mA DC or less.  | C1  |
| Stainless steel amplifier housing <sup>(Note 3)</sup> |                | Amplifier housing material: SCS14A stainless steel (equivalent to SUS316 cast stainless steel or ASTM CF-8M)  | E1  |
| Gold-plate  |                | Gold-plated diaphragm   | A1  |
| Mill Certificate                                      |                | Cover flange, Process connector, Manifold, Orifice, and Spacer  | M12   |
| Pressure test/Leak test Certificate                   |                | Test Pressure: 3.5 MPa{35 kgf/cm <sup>2</sup> }   | Nitrogen(N <sub>2</sub> ) Gas <sup>(Note 5)</sup><br>Retention time: 10 minutes |
|   |                | Test Pressure: 14 MPa{140 kgf/cm <sup>2</sup> }   |   |

T1006.EPS

Note 1: Applicable only for vertical impulse piping types (Installation Code 2, 3, 6 or 7). Long vent material is SUS316.

Note 2: The hardware error indicates faulty amplifier or capsule. Standard output status (without /C1) is up-scale of 110%, 21.6 mA DC or more.

Note 3: Applicable only for electrical Connection code 2, 3 and 4. Not applicable for optional Code P□ and X1.

Note 4: Applicable for Process Connections Code 0 and 5.

Note 5: Pure nitrogen gas is used for Oil-prohibited use (Optional Code K1, K2, K5 and K6).

**Table 1. Measurement Range (Approximate value)**

|   | Orifice Bore (mm) | L Capsule      | M Capsule      | H Capsule     |
|---|-------------------|----------------|----------------|---------------|
| Water Equivalent Maximum Flow Range l/min | 0.508             | 0.016 to 0.049 | 0.022 to 0.157 | 0.07 to 0.225 |
|   | 0.864             | 0.046 to 0.145 | 0.066 to 0.46  | 0.21 to 0.67  |
|   | 1.511             | 0.134 to 0.42  | 0.19 to 1.35   | 0.60 to 1.93  |
|   | 2.527             | 0.36 to 1.15   | 0.52 to 3.6    | 1.65 to 5.2   |
|   | 4.039             | 0.92 to 2.9    | 1.3 to 9.2     | 4.1 to 13.0   |
|   | 6.350             | 2.3 to 7.2     | 3.3 to 23      | 10 to 33      |
| Air Equivalent Maximum Flow Range Nl/min  | 0.508             | 0.44 to 1.40   | 0.63 to 4.4    | 1.98 to 6.4   |
|   | 0.864             | 1.30 to 4.10   | 1.85 to 12.9   | 5.8 to 18.5   |
|   | 1.511             | 3.7 to 11.7    | 5.3 to 37      | 16.7 to 54    |
|   | 2.527             | 10.3 to 32     | 14.6 to 105    | 47 to 150     |
|   | 4.039             | 25 to 79       | 36 to 255      | 113 to 370    |
|   | 6.350             | 63 to 198      | 89 to 630      | 280 to 910    |

T1007.EPS


Note: For details, refer to TI 6P1E2-E.

## 10.4 Dimensions


### ● Model EJA115 [Style: S2]

Unit: mm(approx. inch)


#### Vertical Impulse Piping Type, Manifold upside(INSTALLATION CODE '6')



#### Vertical Impulse Piping Type, Manifold downside(INSTALLATION CODE '7')



#### Horizontal Impulse Piping Type(INSTALLATION CODE '9')



F1002.EPS

Note: When INSTALLATION CODE '2', '3' or '8' is selected, flow direction arrow mark on above figure are reversed.  
(i. e. Arrow head faces toward left.)

\*1: 15 mm (0.59 inch) for right side high pressure. (INSTALLATION CODE '2', '3' or '8')

# INSTALLATION AND OPERATING PRECAUTIONS FOR JIS INTRINSICALLY SAFE EQUIPMENT

Apparatus Certified Under Technical Criteria (IEC-compatible Standards) and from “RECOMMENDED PRACTICES for Explosion-Protected Electrical Installations in General Industries,” published in 1979

## 1. General

The following describes precautions on electrical apparatus of intrinsically safe construction (hereinafter referred to as intrinsically safe apparatus).

Following the Labor Safety and Health Laws of Japan, an intrinsically safe apparatus must undergo type tests in order to be certified by the Technical Institute of Industrial Safety, Inc. These tests are required to satisfy either the technical criteria for electrical machinery and equipment in compliance with explosionproof standards involving inflammable gases or vapors and for machinery and equipment having explosionproof performance (standards notification no. 556 from the Japanese Ministry of Labor) (hereinafter referred to as technical criteria), in conformity with IEC Standards, or the “Recommended Practice for Explosion-Protected Electrical Installations in General Industries,” published in 1979. Such a certified apparatus can be used in hazardous locations where inflammable gases or vapors may be present.

Certified apparatus includes a certification label and an equipment nameplate with the specifications necessary for explosion requirements as well as precautions on explosion protection. Please confirm these precautionary items and use them to meet specification requirements.

For electrical wiring and maintenance servicing, please refer to “Internal Wiring Rules” in the Electrical Installation Technical Standards as well as “USER’S GUIDELINES for Electrical Installations for Explosive Gas Atmospheres in General Industry,” published in 1994.

To meet intrinsically safe requirements, equipment that can be termed an “intrinsically safe apparatus” must:

- (1) be certified by the Technical Institute of Industrial Safety, Inc. in accordance with the Labor Safety and Health Laws of Japan and have the appropriate mark of certification labeled on its case, and
- (2) be used in compliance with the specifications marked on its certification label, equipment nameplate and precautionary information furnished.

Note: Intrinsically safe apparatus satisfy their performance under specific conditions. They are not always absolutely safe under every operational and environmental condition. In other

words, they are not safe products involved with factors such as chemical reactions, geographical changes or the like other than affected by electric energy from the equipment itself.

## 2. Electrical Apparatus of Intrinsic Safety Type of Explosion-Protected Construction

The intrinsic safety type of explosion-protected construction is a method of protection applicable to a circuit or part of a circuit in which, under prescribed test conditions, no spark or thermal effect, whether produced normally or accidentally, is capable of causing a prescribed explosive gas to ignite. In other words, electrical apparatus of this construction is intended to suppress electrical energy thereby preventing ignition of a given explosive gas atmosphere even though spark or high thermal effect occurs in the electric circuitry.

Intrinsically safe electrical apparatus generally comprise intrinsically safe apparatus installed in a hazardous location and a safety barrier (associated apparatus), installed in a non-hazardous location, aimed at preventing electrical energy from flowing into the electric circuitry of intrinsically safe apparatus.

However, battery-operated, portable intrinsically safe apparatus or the like may be used alone.

## 3. Terminology

- (1) Intrinsically safe apparatus: Electrical apparatus in which all the circuits are intrinsically safe circuits.
- (2) Associated apparatus: Electrical apparatus in which there are both intrinsically safe circuits and non-intrinsically safe circuits that can affect the safety of intrinsically safe circuits.
- (3) Safety barrier: A specific type of associated apparatus, which consists mainly of safety barrier elements, and serves to limit the flow of excessive electrical energy, which is capable of causing ignition of a given explosive gas or vapour of a non-intrinsically safe circuit into concerned intrinsically safe circuits.
- (4) Apparatus of category “ia”: Intrinsically safe electrical apparatus and associated apparatus which are incapable of causing ignition of a given explosive gas or vapour with the appropriate safety factors such as:

- when up to two countable faults are applied and, in addition,
  - when non-countable faults produce an onerous condition.
- (5) Apparatus of category “ib”: Intrinsically safe electrical apparatus and associated apparatus which are incapable of causing ignition of a given explosive gas or vapour, with the appropriate safety factors such as:
- when up to one countable fault is applied and, in addition,
  - when non-countable faults produce an onerous condition.
- (6) Safety rating: A rating to be designated to intrinsically safe apparatus as well as associated apparatus and is the maximum rating allowable for maintaining intrinsic safety of concerned intrinsically safe circuits.

- (2) For pressure transmitters, pH transmitters, temperature detectors and the like, safety barriers that can be combined are already specified. Other safety barriers cannot be used.

Note 2: Testing Intrinsically Safe System

An assembly (as a system) in which intrinsically safe apparatus and safety barriers are combined is assessed to ensure that its safety requirements are satisfied. A tested and certified system incorporates a certification number (intrinsically safe apparatus and safety barriers have the same certification number).

Note 3: Impossible Combinations of Apparatus Certified Under Different Standards

Intrinsically safe apparatus certified under technical criteria and safety barriers certified under the “Recommended Practice for Explosion-Protected Electrical Installations in General Industries” (1979) and vice versa cannot be combined even if their combination requirements are satisfied.

## 4. Caution on Combining Intrinsically Safe Apparatus and Safety Barriers

- (1) A combination of certified intrinsically safe apparatus and safety barriers needs to satisfy combination requirements. If intrinsically safe apparatus specify safety barriers for combination, safety barriers other than specified cannot be used (see Note 1 for more details).
- (2) Certified intrinsically safe systems specify specific safety barriers in combination with intrinsically safe apparatus. So safety barriers other than specified cannot be used (see Note 2 for more details).
- (3) Other than limitations of combining intrinsically safe apparatus and safety barriers as given in (1) and (2) above, two or more pieces of apparatus certified under different standards cannot be combined with each other (see Note 3 for more details). In addition, bear in mind that classifications of explosion protection such as “IIA,” “IIB” and “IIC” and category “ia” and “ib” limit a combination of intrinsically safe apparatus and safety barriers.

For more details, see the “Type Certificate Guide for Explosion-Protected Construction for Electrical Machinery and Equipment,” issued by the Japanese Ministry of Labour, the Research Institute of Industrial Safety.

Note 1: Testing Apparatus

Intrinsically safe apparatus and safety barriers are assessed individually to ensure that their safety requirements are satisfied. Tested and certified intrinsically safe apparatus and safety barriers incorporate individual certification numbers. A combination of intrinsically safe apparatus and safety barriers involves the following two limitations:

- (1) A safety barrier which meets the combination requirements by referring to its safety rating and combination parameters shall be selected.

## 5. Installation of Intrinsically Safe Apparatus and Safety Barriers

### (1) Classification of installation location

Intrinsically safe apparatus may be installed, depending upon applicable gases, in a hazardous area in Zone 0, 1 or 2 (Note 4 below), where the specified gases are present. However, note that apparatus certified under Technical Criteria, in category “ib” shall be installed only in Zone 1 or 2. Safety barriers (associated apparatus) that are combined with these intrinsically safe apparatus shall be installed only in a non-hazardous area. In cases where safety barriers are installed in a hazardous area, they shall be enclosed, for example, in a flameproof enclosure.

Note 4: Hazardous areas are classified in zones based upon the frequency of the appearance and the duration of an explosive gas atmosphere as follows:

- Zone 0: An area in which an explosive gas atmosphere is present continuously or is present for long periods.
- Zone 1: An area in which an explosive gas atmosphere is likely to occur in normal operation.
- Zone 2: An area in which an explosive gas atmosphere is not likely to occur in normal operation and if it does occur it will exist for a short period only.

### (2) Ambient temperature limits for intrinsically safe apparatus

Intrinsically safe apparatus shall be installed in a location where the ambient temperature ranges from  $-20^{\circ}$  to  $+40^{\circ}\text{C}$  (for those certified under Technical Criteria) or  $-10^{\circ}$  to  $+40^{\circ}\text{C}$  (for those certified under the “Recommended Practice for Explosion-Protected Electrical Installations in General Industries” (1979)). However, some field-mounted

intrinsically safe apparatus may be used at an ambient temperature up to 60°C. So, specifications should be checked before installing intrinsically safe apparatus.

If the intrinsically safe apparatus are exposed to direct sunshine or radiant heat from plant facilities, appropriate thermal protection measures shall be taken.

## 6. Wiring for Intrinsically Safe Circuits

In intrinsically safe construction, safety shall be maintained as an intrinsically safe system involving intrinsically safe apparatus and safety barriers connected thereto, and electrical wiring (through intrinsically safe circuits) interconnected between them. In other words, even when safety requirements are maintained individually by intrinsically safe apparatus and safety barriers, they shall not be affected by electrical or magnetic energy caused by electrical wiring.

To make electrical wiring for intrinsically safe circuits, you must:

- (a) refer to the equipment configuration diagram and make electrical wiring properly;
- (b) prevent intrinsically safe wiring from being contacted with non-intrinsically safe wiring, and separate the intrinsically safe circuit from other electrical circuits;
- (c) prevent intrinsically safe wiring from being electrostatically and magnetically affected by non-intrinsically safe wiring;
- (d) reduce wiring inductance and capacitance produced between the intrinsically safe apparatus and safety barrier where possible, and use a shorter cable between the intrinsically safe apparatus and safety barrier than specified if the maximum permissible inductance of the cable is specified as operating conditions;
- (e) conform to conditions of installation such as wiring method, earthing or the like, if any; and
- (f) protect the outer sheath of cables from damage with appropriate measures.

## 7. Maintenance and Inspection of Intrinsically Safe Apparatus and Safety Barriers

Maintenance and inspection of intrinsically safe apparatus and safety barriers shall be limited to within the instructions described in applicable instruction manuals. If other than this is required, contact the manufacturers. For more information, refer to the “USER’S GUIDELINES for Electrical

Installations for Explosive Gas Atmospheres in General Industry” issued in 1994 by the Japanese Ministry of Labour, the Research Institute of Industrial Safety.

### (1) Requirements for maintenance personnel

Maintenance and inspection of intrinsically safe apparatus and safety barriers shall be conducted by maintenance personnel skilled in intrinsically safe construction and installation of electrical devices as well as capable of applying associated rules.

### (2) Maintenance and Inspection

- (a) Visual inspection  
Visually inspect the external connections of intrinsically safe apparatus and safety barriers, and cables for damage or corrosion as well as other mechanical and structural defects.
- (b) Adjustments  
Zero, span and sensitivity adjustments shall be made with applicable adjusting potentiometers and mechanical adjustment screws.  
These maintenance adjustments shall be made in a non-hazardous location.



### CAUTION

If intrinsically safe apparatus and safety barriers require maintenance service and checking, a gas detector shall be used to ensure that there is no explosive gas in the location (maintenance servicing shall be conducted in a non-hazardous location).

### (3) Repair

Intrinsically safe apparatus and safety barriers shall be repaired by manufacturers.

### (4) Prohibition of modifications and specification changes

Do not attempt to make modifications or change specifications which may affect safety.

# INSTALLATION AND OPERATING PRECAUTIONS FOR JIS FLAMEPROOF EQUIPMENT

## Apparatus Certified Under Technical Criteria (IEC-compatible Standards)

### 1. General

The following describes precautions on electrical apparatus of flameproof construction (hereinafter referred to as flameproof apparatus) in explosion-protected apparatus.

Following the Labour Safety and Health Laws of Japan, flameproof apparatus is subjected to type tests to meet either the technical criteria for explosionproof electrical machinery and equipment (standards notification no. 556 from the Japanese Ministry of Labour) (hereinafter referred to as technical criteria), in conformity with the IEC Standards, or the “Recommended Practice for Explosion-Protected Electrical Installations in General Industries,” published in 1979. These certified apparatus can be used in hazardous locations where explosive or inflammable gases or vapours may be present.

Certified apparatus includes a certification label and an equipment nameplate with the specifications necessary for explosion requirements as well as precautions on explosion protection. Please confirm these precautionary items and use them to meet specification requirements.

For electrical wiring and maintenance servicing, please refer to “Internal Wiring Rules” in the Electrical Installation Technical Standards as well as “USER’S GUIDELINES for Electrical Installations for Explosive Gas Atmospheres in General Industry,” published in 1994.

To meet flameproof requirements, equipment that can be termed “flameproof” must:

- (1) Be certified by a Japanese public authority in accordance with the Labour Safety and Health Laws of Japan and have a certification label in an appropriate location on its case, and
- (2) Be used in compliance with the specifications marked on its certification label, equipment nameplate and precautionary information furnished.

### 2. Electrical Apparatus of Flameproof Type of Explosion-Protected Construction

Electrical apparatus which is of flameproof construction is subjected to a type test and certified by the Japanese Ministry of Labour aiming at preventing explosion caused by electrical apparatus in a factory or any location where inflammable gases or vapours may be present. The flameproof

construction is of completely enclosed type and its enclosure shall endure explosive pressures in cases where explosive gases or vapours entering the enclosure cause explosion. In addition, the enclosure construction shall be such that flame caused by explosion does not ignite gases or vapours outside the enclosure.

In this manual, the word “flameproof” is applied to the flameproof equipment combined with the types of protection “e”, “o”, “i”, and “d” as well as flameproof equipment.

### 3. Terminology

#### (1) Enclosure

An outer shell of an electrical apparatus, which encloses live parts and thus is needed to configure explosion-protected construction.

#### (2) Shroud

A component part which is so designed that the fastening of joint surfaces cannot be loosened unless a special tool is used.

#### (3) Enclosure internal volume

This is indicated by:— the total internal volume of the flameproof enclosure minus the volume of the internal components essential to equipment functions.

#### (4) Path length of joint surface

On a joint surface, the length of the shortest path through which flame flows from the inside to outside of the flameproof enclosure. This definition cannot be applied to threaded joints.

#### (5) Gaps between joint surfaces

The physical distance between two mating surfaces, or differences in diameters if the mating surfaces are cylindrical.

Note: The permissible sizes of gaps between joint surfaces, the path length of a joint surface and the number of joint threads are determined by such factors as the enclosure’s internal volume, joint and mating surface construction, and the explosion classification of the specified gases and vapours.

## 4. Installation of Flameproof Apparatus

### (1) Installation Area

Flameproof apparatus may be installed, in accordance with applicable gases, in a hazardous area in Zone 1 or 2, where the specified gases are present. Those apparatus shall not be installed in a hazardous area in Zone 0.

Note: Hazardous areas are classified in zones based upon the frequency of the appearance and the duration of an explosive gas atmosphere as follows:

Zone 0: An area in which an explosive gas atmosphere is present continuously or is present for long periods.

Zone 1: An area in which an explosive gas atmosphere is likely to occur in normal operation.

Zone 2: An area in which an explosive gas atmosphere is not likely to occur in normal operation and if it does occur it will exist for a short period only.

### (2) Environmental Conditions

The standard environmental condition for the installation of flameproof apparatus is limited to an ambient temperature range from  $-20^{\circ}\text{C}$  to  $+40^{\circ}\text{C}$  (for products certified under Technical Criteria). However, some field-mounted instruments may be certified at an ambient temperature up to  $+60^{\circ}\text{C}$  as indicated on the instrument nameplates. If the flameproof apparatus are exposed to direct sunshine or radiant heat from plant facilities, appropriate thermal protection measures shall be taken.

## 5. External Wiring for Flameproof Apparatus

Flameproof apparatus require cable wiring or flameproof metal conduits for their electrical connections. For cable wiring, cable glands (cable entry devices for flameproof type) to wiring connections shall be attached. For metal conduits, attach sealing fittings as close to wiring connections as possible and completely seal the apparatus. All non-live metal parts such as the enclosure shall be securely grounded. For details, see the "USER'S GUIDELINES for Electrical Installations for Explosive Gas Atmospheres in General Industry," published in 1994.

### (1) Cable Wiring

- Specific cables shall be used as recommended by the "USER'S GUIDELINES for Electrical Installations for Explosive Gas Atmospheres in General Industry," published in 1994.
- In necessary, appropriate protective pipes (conduit or flexible pipes), ducts or trays shall be used for preventing the cable run (outside the cable glands) from damage.
- To prevent explosive atmosphere from being propagated from Zone 1 or 2 hazardous location to any different location or non-hazardous location through the protective pipe or duct, apply sealing of the protective pipes in the vicinity of individual boundaries, or fill the ducts with sand appropriately.
- When branch connections of cables, or cable connections with insulated cables inside the conduit pipes are made, a flameproof or increased-safety connection box shall be used. In this case, flameproof or increased-safety cable glands meeting the type of connection box must be used for cable connections to the box.

### (2) Flameproof Metal Conduit Wiring

- For the flameproof metal conduit wiring or insulated wires shall be used as recommended by the USER'S GUIDELINES for Electrical Installations for Explosive Gas Atmospheres in General Industry, published in 1994.
- For conduit pipes, heavy-gauge steel conduits conforming to JIS C 8305 Standard shall be used.
- Flameproof sealing fittings shall be used in the vicinity of the wiring connections, and those fittings shall be filled with sealing compounds to complete sealing of the apparatus. In addition, to prevent explosive gases, moisture, or flame caused by explosion from being propagated through the conduit, always provide sealing fittings to complete sealing of the conduit in the following locations:
  - (a) In the boundaries between the hazardous and non-hazardous locations.
  - (b) In the boundaries where there is a different classification of hazardous location.
- For the connections of the apparatus with a conduit pipe or its associated accessories, G-type parallel pipe threads (JIS B 0202) shall be used to provide a minimum of five-thread engagement to complete tightness. In addition, since these parallel threads do not have sealing property, nonhardening sealant such as liquid gaskets shall thus be applied to those threads for ensuring waterproofness.
- If metal conduits need flexibility, use flameproof flexible fittings.

## 6. Maintenance of Flameproof Apparatus

To maintain the flameproof apparatus, do the following. (For details, see Chapter 10 “MAINTENANCE OF EXPLOSION-PROTECTED ELECTRICAL INSTALLATION” in the USER’S GUIDELINES for Electrical Installations for Explosive Gas Atmospheres in General Industry.)

### (1) Maintenance servicing with the power on.

Flameproof apparatus shall not be maintenance-serviced with its power turned on. However, in cases where maintenance servicing is to be conducted with the power turned on, with the equipment cover removed, always use a gas detector to check that there is no explosive gas in that location. If it cannot be checked whether an explosive gas is present or not, maintenance servicing shall be limited to the following two items:

- (a) Visual inspection  
Visually inspect the flameproof apparatus, metal conduits, and cables for damage or corrosion, and other mechanical and structural defects.
- (b) Zero and span adjustments  
These adjustments should be made only to the extent that they can be conducted from the outside without opening the equipment cover. In doing this, great care must be taken not to cause mechanical sparks with tools.

### (2) Repair

If the flameproof apparatus requires repair, turn off the power and transport it to a safety (non-hazardous) location. Observe the following points before attempting to repair the apparatus.

- (a) Make only such electrical and mechanical repairs as will restore the apparatus to its original condition. For the flameproof apparatus, the gaps and path lengths of joints and mating surfaces, and mechanical strength of enclosures are critical factors in explosion protection. Exercise great care not to damage the joints or shock the enclosure.
- (b) If any damage occurs in threads, joints or mating surfaces, inspection windows, connections between the transmitter and terminal box, shrouds or clamps, or external wiring connections which are essential in flameproofness, contact Yokogawa Electric Corporation.



### CAUTION

Do not attempt to re-process threaded connections or refinish joints or mating surfaces.

- (c) Unless otherwise specified, the electrical circuitry and internal mechanisms may be repaired by component replacement, as this will not directly affect the

requirements for flameproof apparatus (however, bear in mind that the apparatus must always be restored to its original condition). If you attempt to repair the flameproof apparatus, company-specified components shall be used.

- (d) Before starting to service the apparatus, be sure to check all parts necessary for retaining the requirements for flameproof apparatus. For this, check that all screws, bolts, nuts, and threaded connections have properly been tightened.

### (3) Prohibition of specification changes and modifications

Do not attempt to change specifications or make modifications involving addition of or changes in external wiring connections.

## 7. Selection of Cable Entry Devices for Flameproof Type



### IMPORTANT

The cable glands (cable entry devices for flameproof type) conforming to IEC Standards are certified in combination with the flameproof apparatus. So, Yokogawa-specified cable entry devices for flameproof type shall be used to meet this demand.

### References:


- (1) Type Certificate Guide for Explosion-Protected Construction Electrical Machinery and Equipment (relating to Technical Standards Conforming to International Standards), issued by the Technical Institution of Industrial Safety, Japan
- (2) USER’S GUIDELINES for Electrical Installations for Explosive Gas Atmospheres in General Industry (1994), issued by the Japanese Ministry of Labour, the Research Institute of Industrial Safet



# Customer Maintenance Parts List

## DPharp EJA Series Transmitter Section

DPharp



| Item | Part No.  | Qty | Description  |
|------|---|-----|--|
| 1    | Bellow<br>F9341RA<br>F9341RJ                        | 2   | Cover<br>Cast-aluminum alloy<br>SCS14A stainless steel   |
| 2    | F9341JP   | 2   | O-ring   |
| 3    | Below   | 1   | Case Assembly  |
|      | F9341AA<br>F9341AC<br>F9341AE<br>F9341AH<br>F9341AJ |     | Cast-aluminum alloy for G1/2<br>Cast-aluminum alloy for G1/2 (two electrical connections)<br>Cast-aluminum alloy for 1/2 NPT (two electrical connections)<br>Cast-aluminum alloy for M20 (two electrical connections)<br>Cast-aluminum alloy for Pg13.5 (two electrical connections) |
| 4    | F9341AR   | 1   | SCS14A stainless steel for 1/2 NPT (two electrical connections)  |
| 5    | F9341KA<br>Bellow<br>F9300AG<br>F9303JU             | 4   | Name Plate<br>Screw<br>For cast-aluminum alloy case assembly<br>For SCS14A stainless steel case assembly   |
| 6    | F9341KL   | 1   | Tag Plate  |
| 7-1  | Below<br>F9342BB<br>F9342BH<br>F9342BJ              | 1   | CPU Assembly<br>For BRAIN protocol version (Except JIS Intrinsically safe type)<br>For HART protocol version (Except JIS Intrinsically safe type)<br>For BRAIN protocol version JIS Intrinsically safe type (Optional code /JS1)   |
| 7-2  | F9342AF<br>F9342AM<br>F9342BF                       |     | For BRAIN protocol version (Optional code /F1)<br>For HART protocol version with write protection switch (Optional code /F1)<br>For FOUNDATION Fieldbus protocol   |
| 8    | Y9406ZU   | 2   | Cap Screw  |
| 9    | Y9612YU   | 2   | Screw  |
| 10   | Below<br>F9340NW<br>F9340NX<br>G9330DP<br>G9612EB   | 1   | Plug<br>For Pg13.5<br>For M20<br>For G1/2<br>For 1/2 NPT   |
| 11   | Bellow<br>F9341FM<br>F9341FJ                        | 1   | Cover Assembly<br>Cast-aluminum alloy<br>SCS14A stainless steel  |
| 12   | Below<br>F9342BL                                    | 1   | LCD Board Assembly<br>Without range-setting switch   |
| 13   | F9342BM<br>F9342MK                                  | 2   | With range-setting switch<br>Mounting Screw  |
| 14   | F9300PB   | 2   | Label  |

} For integral indicator




# Customer Maintenance Parts List


## Model EJA115 Low Flow Transmitter (Pressure-detector Section)

*DP* **harp**

### Horizontal Impulse Piping Type



### Vertical Impulse Piping Type



| Item | Part No.   | Qty | Description   |
|------|--|-----|---|
| 1    | —  | 1   | Capsule Assembly (see table 1.and table 2. page 4 ) (Note 1)  |
| 2    | F9300AJ  | 1   | O-Ring  |
| 3    | Below<br>F9340GA<br>F9340GC                                  | 2   | Gasket<br>Teflon-coated SUS316L Stainless Steel<br>Teflon-coated SUS316L Stainless Steel (degreased)  |
| 4    | Below<br>F9340VA<br>F9340VB<br>F9340VC<br>F9340VD            | 2   | Cover Flange, SCS14A Stainless Steel (Note 2)<br>Rc 1/4 } For Horizontal Impulse Piping Type (Note 3)<br>1/4 NPT }<br>Rc 1/4 } For Vertical Impulse Piping Type (Note 3)<br>1/4 NPT }               |
| 5    | Below<br>F9340SA<br>F9340SB                                  | 2   | Vent Plug, SUS316 Stainless Steel<br>R 1/4<br>1/4 NPT   |
| 6    | D0114PB  | 2   | Vent Screw, SUS316 Stainless Steel  |
| 7    | Below<br><br>F9200CS<br>D0114RZ                              | 2   | Drain/Vent Plug, SUS316 Stainless Steel<br>R 1/4<br>1/4 NPT   |
| 8    | Below<br>F9340SC<br>F9340SD                                  | 2   | Drain/Vent Plug, SUS316 Stainless Steel<br>R 1/4<br>1/4 NPT   |
| 9    | F9270HE  | 2   | Drain/Vent Screw, SUS316 Stainless Steel  |
| 10   | Below<br>F9340AB<br>F9340AC                                  | 4   | Bolt<br>SCM435 Chrome Molybdenum Steel<br>SUS630 Stainless Steel  |
| 11   | Below<br><br>F9275KL<br>F9275KH                              | 4   | Nut<br>SCM435 Chrome Molybdenum Steel<br>SUS630 Stainless Steel   |
| 12   | Below<br>D0114RB<br>U0102XC                                  | 4   | Gasket<br>PTFE Teflon<br>PTFE Teflon (degreased)  |
| 13   | Below<br>F9340XW<br>F9340XX                                  | 2   | Process Connector, SCS14A Stainless Steel (Note 2)<br>Rc 1/2<br>1/2 NPT   |
| 14   | Below<br>X0100MN   | 4   | Bolt<br>SCM435 Chrome Molyboleom Steel  |
| 15   | Below<br>F9273DZ<br>F9270AY<br>F9273CZ                       | 4   | SUS630 Stainless Steel<br>Bolt<br>S15C Carbon Steel<br>SUS XM7 Stainless Steel  |
| 16   | Below<br><br>F9270AW<br>F9300TJ<br>F9300TA                   | 1   | Bracket Assembly (Flat type)<br>SECC Carbon Steel<br>SECC Carbon Steel (for Epoxy resin-baked coating)<br>SUS304 Stainless Steel  |
| 17   | Below<br>F9340EA   | 1   | Bracket Assembly (L type)<br>SECC Carbon Steel  |
| 18   | F9340EB<br>F9340EC<br>D0117XL-A                              | 1   | SECC Carbon Steel (for Epoxy resin-baked coating)<br>SUS304 Stainless Steel<br>U-Bolt/Nut Assembly, SUS304 Stainless Steel  |
| 19   | Below<br>F9270AX   | 1   | Bracket (Flat type)<br>SECC Carbon Steel  |
| 20   | Below<br>F9300TN<br>F9300TE<br>F9340EF<br>F9340EG<br>F9340EM | 1   | SECC Carbon Steel (for Epoxy resin-baked coating)<br>SUS304 Stainless Steel<br>Bracket (L type)<br>SECC Carbon Steel<br>SECC Carbon Steel (for Epoxy resin-baked coating)<br>SUS304 Stainless Steel |
| 21   | Below<br>F9304VA<br>F9304VB<br>F9304VC<br>F9304VD            | 1   | Manifold Assembly<br>Orifice Bore : 0.508 mm<br>Orifice Bore : 0.864 mm<br>Orifice Bore : 1.511 mm<br>Orifice Bore : 2.527 mm   |

| Item | Part No. | Qty | Description   |
|------|----------|-----|---|
| 21   | F9304VE  |     | Orifice Bore : 4.039 mm                             |
|      | F9304VF  |     | Orifice Bore : 6.350 mm                             |
| 22   | F9275ZT  | 1   | Spacer, SUS316 Stainless Steel (Note 2)             |
| 23   | Below    | 1   | Orifice, SUS316 Stainless Steel (Note 2)            |
|      | D0117BW  |     | Orifice Bore : 0.508 mm                             |
|      | D0117BX  |     | Orifice Bore : 0.864 mm                             |
|      | D0117BY  |     | Orifice Bore : 1.511 mm                             |
|      | D0117BZ  |     | Orifice Bore : 2.527 mm                             |
|      | D0117CA  |     | Orifice Bore : 4.039 mm                             |
|      | D0117CB  |     | Orifice Bore : 6.350 mm                             |
| 24   | F9273HC  | 1   | Gasket, PTFE Teflon (Note 2)                        |
| 25   | F9275ZR  | 1   | Manifold, SUS316 Stainless Steel (Note 2)           |
| 26   | Below    | 4   | Bolt  |
|      | F9147AF  |     | Chrome Molybdenum Steel                             |
|      | A0116WT  |     | SUS630 Stainless Steel                              |
| 27   | Below    | 2   | Vent Plug (degreased), SUS316 Stainless Steel       |
|      | F9275EC  |     | R 1/4   |
|      | F9275ED  |     | 1/4 NPT   |
| 28   | F9275EE  | 2   | Needle Assembly (degreased), SUS316 Stainless Steel |

(Note 1) In case of Degrease cleansing treatment (Optional Code/K1 or K5), consult YOKOGAWA local office.  
(However, see Table 1 and 2 in case of Optional Code/K2 or K6)

(Note 2) In case of Degrease cleansing treatment (Optional Code/K1, K2, K5 or K6), consult YOKOGAWA local office.

(Note 3) These Cover Flanges shall be applied to the model with the Style Code "S2" which was supplied from Aug. 16, 1996.

Table 1. Capsule Assembly Part Number (Item 1)  
For General-use type, Flameproof type and Intrinsically safe type (Except JIS Intrinsically safe type)

| Installation of Transmitter    | High Pressure Side | Capsule Code | Part No. (*1) | Part No. (*2) |
|--------------------------------|--------------------|--------------|---------------|---------------|
| Horizontal Impulse Piping Type | Right              | L            | F9349AA       | F9352AA       |
|                                |                    | M            | F9349BA       | F9352BA       |
|                                |                    | H            | F9349CA       | F9352CA       |
|                                | Left               | L            | F9349AB       | F9352AB       |
|                                |                    | M            | F9349BB       | F9352BB       |
|                                |                    | H            | F9349CB       | F9352CB       |
| Vertical Impulse Piping Type   | Right              | L            | F9349AC       | F9352AC       |
|                                |                    | M            | F9349BC       | F9352BC       |
|                                |                    | H            | F9349CC       | F9352CC       |
|                                | Left               | L            | F9349AD       | F9352AD       |
|                                |                    | M            | F9349BD       | F9352BD       |
|                                |                    | H            | F9349CD       | F9352CD       |

\*1. Silicone oil filled capsule (Standard)

\*2. Fluorinated oil filled capsule ( for oil-prohibited-use : Optional Code /K2 or K6)

Table 2. Capsule Assembly Part Number (Item 1) For JIS Intrinsically safe type

| Installation of Transmitter    | High Pressure Side | Capsule Code | Part No. (*1) | Part No. (*2) |
|--------------------------------|--------------------|--------------|---------------|---------------|
| Horizontal Impulse Piping Type | Right              | L            | F9349NA       | F9352NA       |
|                                |                    | M            | F9349PA       | F9352PA       |
|                                |                    | H            | F9349QA       | F9352QA       |
|                                | Left               | L            | F9349NB       | F9352NB       |
|                                |                    | M            | F9349PB       | F9352PB       |
|                                |                    | H            | F9349QB       | F9352QB       |
| Vertical Impulse Piping Type   | Right              | L            | F9349NC       | F9352NC       |
|                                |                    | M            | F9349PC       | F9352PC       |
|                                |                    | H            | F9349QC       | F9352QC       |
|                                | Left               | L            | F9349ND       | F9352ND       |
|                                |                    | M            | F9349PD       | F9352PD       |
|                                |                    | H            | F9349QD       | F9352QD       |

\*1. Silicone oil filled capsule (Standard)

\*2. Fluorinated oil filled capsule ( for oil-prohibited-use : Optional Code /K2 or K6)

# REVISION RECORD

Title: Model EJA115 Low Flow Transmitter  
Manual No.: IM 1C22K1-01E

| Edition | Date      | Page   | Revised Item  |
|---------|-----------|--|---|
| 7th     | Mar. 1998 | 1-1<br>6-1<br>11-1<br>11-2<br>11-3<br>2-9+<br>CMPL<br><br>CMPL         | 1 • Add FOUNDATION Fieldbus protocol version to 'NOTE' notice.<br>6.1 • Add Item 6 to the Wiring Precautions.<br>11.1.1 • Add FOUNDATION Fieldbus protocol.<br>11.1.2 • Add Output signal code F.<br>11.1.3 • Add Optional code A1.<br>• Change the figure of terminal configuration.<br>CMPL 1C22A1-02E 3rd ⇒ 4th<br>Page 2 • Add Item 7-2.<br>CMPL 1C22K1-01E 4th ⇒ 5th<br>Page 4 • Add Optional code K5 and K6.  |
| 8th     | Sep. 1998 | 2-14<br><br>2-15<br>8-20<br>11-2<br>CMPL                               | 2.10 • Delete EMC Conformity Standards Tables and move the section to Page 2-14.<br>2.10 • Remove Page 2-15.<br>8.3.2(10) • Correction made in BURN OUT figure.<br>11.1.2 • Add Electrical connection code 7, 8, and 9.<br>CMPL 1C22A1-02E 4th ⇒ 5th<br>Page 2 • Add Part No. to Item 3 (For PG13.5 and M20).<br>• Add Part No. to Item 10 (For 1/2NPT, PG13.5, and M20).   |
| 9th     | Feb. 2000 | –<br><br><br>2-9<br><br>6-1<br>6-3<br><br>8-4<br>–<br><br>10-5<br>CMPL | Changed to Electronic File Format<br>Revised a book in a new format.<br>(The location of contents and the associated page numbers may not coincide with the one in old editions.)<br>Major Revised Items:<br>1. Explosion class and option code of JIS flameproof approval.<br>Explosion class: Ex ds IIC T4(old) to Ex do IIC T4X(new).<br>Option code: /JF1(old) to /JF3(new)<br>2. Option code for flameproof packing adapter for JIS flameproof approval.<br>Option code: /G1 and /G2(old) to /G11 and /G12(new)<br>3. Add "Pa" and "hPa" as the unit for calibration range.<br>4. Part number change for CPU Board Assembly.<br><br>2.9 • Add Figure 2.3 Example of using DCS.<br>• Add Figure 2.4 Selecting Cables.<br>2.10 • Add AS/NZS 2064 1/2 to EMI, EMC Conformity Standards.<br>6.2 • Add selection in the case of JIS flameproof type.<br>6.4.2 • Change option code for flame packing adapter.<br>Option code: G1 and G2 ⇒ G11 and G12<br>Change Applicable cable O.D. and Identifying mark.<br>Part number: G9601AH ⇒ G9601AM<br>Change the figure of flame proof packing adapter in Figure 6.4.2c.<br>8.3.1 • Add Pa and hPa to C20 and D31.<br>– • Installation and Operating Precautions for JIS Intrinsically Safe and Explosionproof Equipment:<br>EX-A01E ⇒ EX-A03E, EX-B01E ⇒ EX-B03E<br>10.3 • Add Optional code F1.<br>CMPL 1C22A1-02E 5th ⇒ 6th<br>• Change a format.<br>• Change and add Part No. of Item 7-1, CPU assembly:<br>Change; F9342BC ⇒ F9342BB, F9342BK ⇒ F9342BJ<br>Add; F9342AF, F9342AM<br>• Change Part No. of Item 10, Plug:<br>G9330DK ⇒ G9330DP<br>CMPL 1C22K1-01E 6th<br>• Change a format. |

REVISION RECORD.EPS

IM 1C22K1-01E

