Strategy for Achieving True Sub-Micron Orbit Stabilization at the Advanced Photon Source

Glenn Decker

Argonne National Laboratory Advanced Photon Source AOD Diagnostics



APS Orbit Correction System Components

- 360 broadband RF BPMs
- 48 narrowband RF BPMs (mounted on ID vacuum chambers)
- 48 insertion device X-ray BPMs
- 38 bending magnet X-ray BPMs
- 317 combined-function horizontal / vertical corrector magnets
- 21 VME crates, each with 2 DSP boards for real-time feedback
- One additional DSP board used in feedback crates for X-ray and narrowband BPM data acquisition and filtering.
- Singular Value Decomposition (SVD) algorithm used in DC and AC systems.
- Workstation-based algorithm operates up to 0.1 Hz
- Real-time algorithm operates from 0.1 to 60 Hz
 - Access to 38 "fast" correctors
 - Access to all RF and X-BPM data (not all used in algorithm)



Systematic Effects Impacting APS Orbit Correction

RF BPM systematic effects

- Timing / trigger stability
- Intensity dependence
- Bunch pattern dependence
- The "rogue" microwave chamber modes
- Electronics thermal drift

X-ray BPM systematic effects


- Stray radiation striking X-bpm blade pickups
- X-bpm blade misalignment
- Electronics thermal drift
- ID Gap-dependent effects (e.g. sensitivity, steering)

Extrinsic systematic effects (noise sources)

- Magnet power supply noise / ripple
- RF system high voltage power supply
- Mechanical vibration
- Thermal effects (Tunnel air / water temperature)
- Earth tides
- Insertion device gap changes




One Sector of the Advanced Photon Source Storage Ring



Argonne National Laboratory Advanced Photon Source AOD Diagnostics



PAC'01 Glenn Decker June 20, 2001



Legend:

C: Corrector Magnet

•: RF Beam Position Monitor

X: X-ray Beam Position Monitor

Q: Quadrupole

BM: Bending Magnet

ID: Insertion Device

Config.	BPMs	Correctors
Global	11 RF (all)	2
Local - 1	P1 or P2	4
Local - 2	P1 and P2	4


XBPM weight = 5; RFBPM weight = 1


Argonne National Laboratory Advanced Photon Source AOD Diagnostics





Operational Experience with X-ray BPMs PAC 2001, June 18-22, 2001, Chicago,IL Om Singh and Glenn Decker

Spectrum of Beam Motion Averaged over ID Source Points











Variation of Particle Trajectory Through Insertion Device vs Gap




Advanced Photon Source
AOD Diagnostics




PAC'01 Glenn Decker June 20, 2001



Variation of RF bpm's while cycling 33ID from 15 to 30 mm gap- FF on vs off



Sector 32-ID X-bpm Feedback Results



Advanced Photon Source
AOD Diagnostics



Glenn Decker June 20, 2001