# OPERATIONAL EXPERIENCE WITH X-RAY BEAM POSITION MONITORS IN ORBIT FEEDBACK AT THE ADVANCED PHOTON SOURCE

O. Singh and G. Decker

Argonne National Laboratory Advanced Photon Source AOD Diagnostics



# OPERATIONAL EXPERIENCE WITH XBPM IN ORBIT CONTROL

#### **ACKNOWLEDGEMENTS**

M. Borland, J. Carwardine, L. Emery, L. Erwin, S. Farrell, H. Friedsam, C. Gold, M. Hahne, R. Laird, F. Lenkszuz, A. Pietryla, M. Ramanathan, T. Roberts, S. Sharma, D. Shu

Argonne National Laboratory Advanced Photon Source AOD Diagnostics



# OPERATIONAL EXPERIENCE WITH X-RAY BPM IN ORBIT CONTROL

- Motivation
- Upgrades
- Orbit Control Configuration
- Bending Magnet X-ray BPM
- Insertion Device X-ray BPM
- Summary and Future Plans



# **MOTIVATION**

#### Why Use XBPM for Orbit Contol at APS?


- XBPM can provide <u>better quality beam position measurements</u> thermally insulated and vibration-dampened support structure;
  - Very small dependence on environmental temperature changes
  - Vibration displacement < 0.1 micron rms, ~ 1 50 Hz
- XBPMs are <u>closer to the users</u>, providing more realistic user's beam position information (11 to 20 meters from source point).
- XBPM provides <u>increased angular measurement resolution</u> up to factor of 8 compared to RFBPM
- XBPMs can also be used to <u>measure ID steering effects</u> as gap varies



# **UPGRADES**

- Upgrade XBPM data acquisition system (Frank Lenkszus TOPB011)
- Upgrade <u>feedback/feedforward</u> correction strategy (Glenn Decker WOPA003)
  - DC Orbit and Real Time Feedback
  - Feedforward Correction reduces ID steering effects to the electron orbit outside the ID
- Interface XBPM translation stages to EPICS -
  - to expedite blade alignments
  - to calibrate XBPMs electronics/cross-calibrate RFBPMs.
- Replace and/or repair radiation damaged motors and few faulty stages
- Eliminate <u>background stray radiations</u> on ID XBPMs modify lattice





Legend:

**C:** Corrector Magnet

•: RF Beam Position Monitor

X: X-ray Beam Position Monitor

Q: Quadrupole

**BM: Bending Magnet** 

**ID: Insertion Device** 


Config.	BPMs	Correctors
Global	11 RF (all)	2
Local - 1	P1 or P2	4
Local - 2	P1 and P2	4

XBPM weight = 5; RFBPM weight = 1

Argonne National Laboratory Advanced Photon Source AOD Diagnostics



#### **BM X-ray BPM Orbit Feedback Results for 6 Beamlines**



# **Insertion Device X-ray BPMs**

- ID XBPM measurements at a given ID are severely affected with gap change -
  - 1. Background stray radiation
  - 2. ID steering effects
    - Causes distortion to the electron orbit external to the ID
    - Causes distortion to the electron orbit internal to the ID



# **Insertion Device X-ray BPMs**


# Strategy to reduce background and ID steering effects:

- 1. Background stray radiation:
  - Lattice modification eliminates this radiation
  - But it adds 1-mrad correction-generated radiation whose effects are reduced by <u>Background subtraction</u> procedure
- 2. ID steering effects on the electron orbit outside ID are reduced by implementing feedforward (FF) correction by using 2 correctors
- 3. ID steering effects on the electron orbit inside ID and the effects of variation in blade response can be lumped into XBPM offset



# **Reducing Background Radiation by Lattice modification**


Stray radiation from upstream dipole, quadrupoles, sextupoles and correctors



Stray radiation from downstream dipole, quadrupoles, sextupoles and correctors


Argonne National Laboratory Advanced Photon Source AOD Diagnostics





Argonne National Laboratory Advanced Photon Source AOD Diagnostics






Argonne National Laboratory Advanced Photon Source AOD Diagnostics



# Stray Radiation Reduction due to lattice Modification for ID 02 and ID32



Without lattice modification sum signals are between 15 to 30 microAmps with gap open to 60 mm.


- S02-ID P2 (standard P2 geometry)
- ✓ S02-ID P1
- ▼ S32-ID P1



Argonne National Laboratory Advanced Photon Source AOD Diagnostics



# **BACKGROUND SUBTRACTION**




Adjusted=(Raw-Offset)normalized

Position = (Delta/Sum)<sub>adjusted</sub>

Argonne National Laboratory Advanced Photon Source AOD Diagnostics






**AOD Diagnostics** 



PAC 2001, June 18-22, 2001, Chicago, IL Om Singh and Glenn Decker

#### Fixed Gap Results with ID X-ray BPM Feedback ON for two Beamlines



#### **STATUS**


- XBPM data acquisition installation completed for 14 sectors others to be done by October, 2001.
- BM XBPMs orbit feedback commissioned for 8 beamlines
- Lattice modification completed for 9 out 22 IDs.
- ID XBPM orbit feedback under test at a fixed gap

#### **PLANS**

- Implement feedforward correction for all IDs
- Measure ID XBPM based "offset" as gap changes
- Collaborate with users to determine orbit stabilty as gap changes
- Increase correction bandwidth for DC orbit feedback to > 1 Hz
- Upgrade real time feedback system to include XBPMs



#### Variation of Particle Trajectory Through Insertion Device vs Gap



Argonne National Laboratory
Advanced Photon Source
AOD Diagnostics



PAC 2001, June 18-22, 2001, Chicago,IL
Om Singh and Glenn Decker

#### Variation of RF bpm's while cycling 33ID from 15 to 30 mm gap- FF on vs off

